
KENTUCKY AMBIENT/WATERSHED WATER QUALITY MONITORING STANDARD OPERATING PROCEDURE MANUAL



Environmental and Public Protection Cabinet Department for Environmental Protection Division of Water August 2005



The Environmental and Public Protection Cabinet does not discriminate on the basis of race, color, national origin, sex, age, religion or disability and provides, on request, reasonable accommodations, including auxiliary aids and services necessary to afford an individual with a disability an equal opportunity to participate in all services, programs and activities. To request materials in an alternative format, contact the Kentucky Division of Water, 14 Reilly Road, Frankfort, KY 40601 or call (502) 564-3410. Hearing- and speech-impaired persons can contact the agency by using the Kentucky Relay Service, a toll-free telecommunications device for the deaf (TDD). For voice to TDD, call 800-648-6057. For TDD to voice, call 800-648-6056.

Kentucky Ambient/Watershed Water Quality **Monitoring Standard Operating** Procedure Manual 2005

Kentucky Department for Environmental Protection Division of Water Water Quality Branch

This report has been approved for release:

David W. Morgan, Director Division of Water

8/23/05

Table of Contents

<u>Chapter</u> <u>Page</u>
I Introduction
II Planning2
Step 1 Selection of Potential Water Quality Sampling Stations
Step 2 Preparation of a Sample Plan
Step 3 Location and Description of the Sampling Locations
III Preparation9
Step 1 Containers and Preservation9
Step 2 Assembling and calibrating sampling equipment
Step 3 Cleaning Sampling Equipment
IV Sampling11
Step 1 Health and Safety Guidelines
Step 2 Field Measurements
Step 3 Collection of Representative River Water Samples
Step 4 Collection of Representative Lake/Reservoir Water Samples20
Step 5 Preservation29
Step 6 Handling and Packing of Samples31
V Data Management33
Appendix A Traffic Control at Bridge Crossings34
Appendix B Water Sampling Supplies Checklist
Appendix C Field Meter Audit41
Appendix D Tables for Dissolved Oxygen Concentration, Oxygen Solubility in
Water, and Correction Factor for Oxygen Saturation at Altitude43
Appendix E Kentucky Ambient/Watershed Monitoring Assessment Program
Contamination Control53
Appendix F Quality Control Design56
Appendix G Chain of Custody60
Appendix H Lake Data Sheet63
Appendix I Dissolved Metals – Clean Field Sampling Protocol

Tables

<u>Table</u>	<u>I</u>	<u>Page</u>
Table 1	Kentucky primary water quality monitoring stations	3
Table 2	Containers and preservatives needed for ambient/watershed samples	9
Table 3	Kentucky clean lakes monitoring stations	22
Table A-1	General guidelines for work zone approach and taper zone lengths on	
	two-lane roads	36
Table D-1	Kentucky division of water saturation concentration of dissolved	
	oxygen by elevation	44
Table D-2	Solubility of oxygen in pure water at different temperatures	52
Table D-3	Correction factor for oxygen satureation at varying altitudes	52
Table F-1	Quality control objectives (RPD, relative percent difference)	57
Table F-2	Collection frequencies for routine quality control samples	59

KENTUCKY AMBIENT/ WATERSHED WATER QUALITY MONITORING STANDARD OPERATING PROCEDURE MANUAL

I. INTRODUCTION

Critical to securing legally defensible water quality data is the implementation of a rigorous QA/QC program. Addressing the needs and objectives of a monitoring study/program is the initial step to assure the success and utility of the program and data. However, without documentation and adherence to standard operating procedures, the information generated is of questionable value. Since the collection of the water sample and associated field measurements are such a vital step in the information system, this manual documents the operational procedures and quality assurance for the Kentucky Ambient/Watershed Monitoring Assessment program.

The Kentucky Ambient/Watershed Monitoring Assessment program is designed to assess the status and trends in the quality of Kentucky's surface water resources and to develop an understanding of the major factors that affect water-quality conditions and use attainment. The Kentucky Ambient/Watershed Monitoring Assessment program consists of three components. These include the Ambient Monitoring Assessment, the Watershed Monitoring Assessment and the Lake Monitoring Assessment. The goals of the Ambient Monitoring Assessment are to characterize background conditions of water quality variables, assess use attainment and determine long-term trends in rivers and streams across Kentucky. The goals of the Watershed Monitoring Assessment are to characterize water-quality variable conditions and assess use attainment over an intensively sampled one-year period. The goals of the Lake Monitoring Assessment are to determine the trophic status, use support and long-term trends in water quality.

Much of the guidance for developing this Standard Operating Procedure Manual came from U.S. Geological Survey National Field Manual (http://water.usgs.gov/owq/FieldManual/). This national field manual presents the rationale and operating procedures for water collection activities conducted by the USGS.

II. PLANNING

Before water quality sampling can be conducted, information about sampling locations, sampling variables and methods is needed. Sampling cannot begin until a plan has been developed that specifies the locations, number of samples, variables to be sampled, numbers and kinds of QA/QC samples and desired quality of the data. Samplers are responsible for collecting and handling samples and keeping records in accord with the sampling plan.

Health and Safety

Before attempting any water quality sampling, one must be aware of the applicable health and safety requirements. Because sample collection often is done at contaminated sites or far from immediate medical attention, it is important to follow all safety requirements and guidelines (STEP 7). In addition, since sampling is often conducted at highway bridge crossings, it is important to develop a highway safety plan for each site. Appendix A presents a model safety plan for bridge crossing sampling sites.

Step 1. Selection of Potential Water Quality Sampling Stations

A water quality station is a specific location on a water body from which a sample is collected. Its location is critical to the success of the monitoring program. Ideally, location of river monitoring stations should incorporate the following characteristics:

- 1. safety of samplers;
- 2. accessibility;
- 3. proximity to a current hydrological recording station;
- 4. transport time to laboratories;
- 5. conformation of stream reach sampled (straight channels are preferred); and
- 6. reach mixing; sites upstream or downstream of major tributaries or point sources should be avoided to minimize problems caused by backwater effects or poorly mixed flows.

If possible, a reconnaissance visit should be made to each site prior to sample collection. If the river is flowing, measurement of temperature, pH, specific conductance and dissolved oxygen at intervals across a transect and at depths will indicate the degree of mixing at the site. The variability in these field measurements will aid in the decision to sample a given location.

The Water Quality Branch selects water quality monitoring locations for the Ambient Monitoring Assessment program. Ambient Monitoring Assessment locations, which monitor long-term river conditions, are located within hydrologic units using the approach of Ward and others (op. cit.). The ambient network was expanded to 70 stations in 1998 with the initiation of the watershed initiative. This increase was made possible by decreasing sampling from monthly to bimonthly. Table 1 provides a list of the ambient network stations.

Table 1. Kentucky primary water quality monitoring stations.

Major River Basin	Station	Hydro Unit	Mile- Point	Location	Latitude	Longitude	Latitude	Longitude	Drainage Area (mi2)	Type
Wajor River Basin	Station	<u>Omt</u>	1 OIIIt	Location	Latitude	Longitude	Latitude	Longitude	<u>(IIII2)</u>	Туре
Big Sandy										
Tug Fork	2	05070201	35.1	at Kermit, WV	37 50 16	82 24 35	37.83778	-82.40972	1280	hydrologic unit index site
Tug Fork	3	05070201	77.7	at Freeburn	37 33 58	82 08 38	37.56611	-82.14389	271	mid-hydrologic unit index
Levisa Fork	6	05070202	114.6	nr Pikeville	37 27 51	82 31 33	37.46417	-82.52583	1232	hydrologic unit index site
Levisa Fork	64	05070203	29.6	nr Louisa	38 04 50	82 36 01	38.08056	-82.60028	2326	hydrologic unit index site
Levisa Fork	94	05070203	75	at Auxier	37 43 44.2	82 45 16.1	37.72894	-82.75447	1726	mid-hydrologic unit index
Beaver Creek	95	05070203	1	Allen	37 36 09.6	82 43 39.4	37.60267	-82.72761	240	major tributary
Johns Creek	96	05070203	26.6	at McCombs	37 39 19.1	82 31 33.2	37.65531	-82.52589	168	inflow to Dewey Lake;ma
Little Sandy										
Little Sandy River	49	05090104	13.2	Argillite	38 29 26	82 50 03	38.49056	-82.83417	522	hydrologic unit index site
Tygarts Creek										
Tygarts Creek	111	05090103	23.5	nr Lynn	38 35 58.9	82 57 10.1	38.59969	-82.95281	242	hydrologic unit index site
Ohio River Tributaries										
Kinniconick Creek	63	05090201	10.4	nr Garrison	38 34 28.6	83 11 17.0	38.57461	-83.18806	175	major tributary
Licking River										
Licking River	62	05100101	226.4	at West Liberty	37 54 53	83 15 43	37.91472	-83.26194	335	inflow to Cave Run Lake
Slate Creek	93	05100101	10	nr Owingsville	38 08 29.3	83 43 43.0	38.14147	-83.72861	230	major tributary
Licking River	61	05100101	78.2	at Claysville	38 31 14	84 11 00	38.52056	-84.18333	1993	mid-hydrologic unit index
Licking River	112	05100101	56.3	at Butler	37 47 22.9	84 22 03.0	37.78969	-84.36750	3385	hydrologic unit index site
North Fork Licking River	60	05100101	6.9	nr Milford	38 35 50	84 09 20	38.59722	-84.15556	290	major tributary

Table 1 (cont.). Kentucky primary water quality monitoring stations.

									Drainage	
		Hydro	Mile-						Area	
Major River Basin	<u>Station</u>	<u>Unit</u>	<u>Point</u>	<u>Location</u>	<u>Latitude</u>	Longitude	<u>Latitude</u>	Longitude	<u>(mi2)</u>	Туре
Licking River (cont.)										
Stoner Creek	101	05100102	0.6	nr Ruddles Mill	38 18 10.3	84 14 58.9	38.30286	-84.24969	284	major tributary
Salt River										
Salt River	29	05140102	22.9	at Shepardsville	37 59 06	85 43 03	37.98500	-85.71750	1197	hydrologic unit index site
Salt River	52	05140102	82.5	at Glensboro	38 00 08	85 03 35	38.00222	-85.05972	172	major reservoir inflow
Brashears Creek	105	05140102	1.2	at Taylorsville	38 02 14	85 20 26	38.03722	-85.34056	262	major tributary
Floyds Fork	100	05140102	7.4	nr Shepardsville	38 02 06	85 39 34	38.03500	-85.65944	259	major tributary
Rolling Fork	57	05140103	12.3	nr Lebanon Jct	37 49 23	85 44 53	37.82306	-85.74806	1375	hydrologic unit index site
Beech Fork	41	05140103	48.0	nr Maud	37 49 58	85 17 46	37.83278	-85.29611	436	major tributary
Kentucky River										
Eagle Creek	22	05100205	21.5	Glencoe	38 42 22	84 49 32	38.70611	-84.82556	437	hydrologic unit index site
Kentucky River	24	05100205	64.8	Frankfort	38 12 46.3	84 52 21.5	38.21286	-84.87264	5412	hydrologic unit index site
Kentucky River	66	05100205	30.5	Lockport	38 26 42	84 57 25	38.44500	-84.95694	6180	hydrologic unit index site
Kentucky River	67	05100205	118.8	High Bridge	37 49 08.9	84 42 23.3	37.81914	-84.70647	5036	hydrologic unit index site
Elkhorn Creek	98	05100205	10.3	Peaks Mill	38 16 06.9	84 48 52.3	38.26858	-84.81453	473	major trib
Dix River	45	05100205	34.7	nr Danville	37 38 30	84 39 39	37.64167	-84.66083	318	hydrologic unit index site
Silver Creek	99	05100205	5.9	Ruthion	37 43 58	84 26 13.2	37.73278	-84.43700	100	major trib
Kentucky River	58	05100204	191.2	nr Trapp	37 50 48	84 04 52	37.84667	-84.08111	3236	hydrologic unit index site
Red River	46	05100204	21.6	Clay City	37 51 55	83 56 00	37.86528	-83.93333	362	hydrologic unit index site
North Fork Kentucky River	31	05100201	49.7	Jackson	37 33 04	83 23 04	37.55111	-83.38444	1101	hydrologic unit index site
Troublesome Creek	90	05100201	7.2	nr Clayhole	37 28 01.7	83 16 46.2	37.46714	-83.27950	187	major trib
Middle Fork Kentucky River	32	05100202	8.4	Tallega	37 33 18	83 35 38	37.55500	-83.59389	537	hydrologic unit index site

Table 1 (cont.). Kentucky primary water quality monitoring stations.

Table 1 (cont.). Rentuck	Pillimy	Hydro	Mile-						Drainage	
Major River Basin	Station	Unit		Location	Latitude	Longitude	Latitude	Longitude	Area (mi2)	Type
Kentucky River (cont.)										
South Fork Kentucky	33	05100203	12.1	Booneville	37 28 30	83 40 14	37.47500	-83.67056	722	hydrologic unit index site
River										
Red Bird River	91	05100203	50.4	nr Oneida	37 14 12.6	83 38 42.5		-83.64514	190	major trib
Goose Creek	92	05100203	3.4	nr Oneida	37 14 13.3	83 40 15.6	37.23703	-83.67100	250	major trib
C 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1										
Cumberland River	0.6	05120101	cc1	. С 1 :	26 42 10 7	02 27 21 0	26.7221.4	02 (2552	770	
Cumberland River	86	05130101	661	at Calvin	36 43 19.7	83 37 31.9	36.72214	-83.62553	770	mid-hydrologic unit inde
Cumberland River	9	05130101	562.6	at Cumberland Falls	36 50 08	84 20 25	36.83556	-84.34028	1977	hydrologic unit index site
Clear Fork	87	05130101	0.9	nr Williamsburg	36 43 33.2	84 08 32.6	36.72589	-84.14239	370	major tributary
Rockcastle River	10	05130102	24.7	at Billows	37 10 17	84 17 48	37.17139	-84.29667	604	hydrologic unit index site
Horse Lick Creek	51	05130102	0.1	nr Lamero	37 19 13.3	84 08 19.2	37.32036	-84.13867	62	outstanding state resource
Cumberland River	7	05130103	422.7	nr Burkesville	36 44 46.5	85 22 18.2	36.74625	-85.37172	6053	hydrologic unit index site
Buck Creek	88	05130103	12.3	nr Dykes	37 03 36.3	84 25 34.9	37.06008	-84.42636	294	major tributary
South Fork Cumberland R	8	05130104	44.8	at Blue Heron	36 40 13	84 32 56	36.67028	-84.54889	954	hydrologic unit index site
Little River	43	05130205	24.4	nr Cadiz	36 50 26	87 46 39	36.84056	-87.77750	269	major tributary
Red River	69	05130205	49	nr Keysburg	36 38 26.9	86 58 44.7	36.64081	-86.97908	509	hydrologic unit index site
Green River										
Green River	18	05110001	226	at Munfordville	37 16 07.2	85 53 07.0	37.26867	-85.88528	1673	hydrologic unit index site
Green River	76	05110001	334.2	nr Neatsville	37 11 30.9	85 07 49.1	37.19192	-85.13031	339	major reservoir inflow
Nolin River	21	05110001	80.9	at White Mills	37 33 18	86 01 52	37.55500	-86.03111	357	major reservoir inflow; m
Russell Creek	77	05110001	10	nr Bramlett	37 10 04.1	85 28 12.6	37.16781	-85.47017	289	major tributary
Little Barren River	78	05110001	6.3	nr Monroe	37 13 35.2	85 40 39.2	37.22644	-85.67756	256	major tributary
Bear Creek	75	05110001	11.8	nr Huff	37 14 55.8	86 21 40.4	37.24883	-86.36122	159	major tributary
Barren River	72	05110002	1	Woodbury	37 10 23.8	86 37 23.5	37.17328	-86.62319	1968	hydrologic unit index site
				-						

Table 1 (cont.). Kentucky primary water quality monitoring stations.

		Hydro	Mile-						Drainage	
Major River Basin	Station	<u>Unit</u>	<u>Point</u>	Location	<u>Latitude</u>	Longitude	<u>Latitude</u>	Longitude	Area (mi2)	Type
Green River (Cont.)										
Barren River	73	05110002	113.8	nr Holland	36 41 46.8	86 02 48.2	36.69633	-86.04672	398	major reservoir inflow
Drakes Creek	74	05110002	8	nr Bowling Green	36 56 05.7	86 23 34.7	36.93492	-86.39297	502	major tributary
Green River	55	05110003	72	at Livermore	37 29 03.1	87 08 04.0	37.48419	-87.13444	6431	hydrologic unit index site
Mud River	56	05110003	17.4	nr Gus	37 07 24	86 54 02	37.12333	-86.90056	268	major tributary
Green River	103	05110003	150	nr Woodbury	37 11 00.4	86.36.57.5	37.18344	-86.61597	3140	hydrologic unit index site
Rough River	14	05110004	62.5	nr Dundee	37 33 46	86 46 15	37.56278	-86.77083	757	mid-hydrologic unit inde:
Rough River	54	05110004	1	nr Livermore	37 29 03.1	87 07 07.6	37.48419	-87.11878	1068	hydrologic unit index site
Panther Creek	70	05110005	5.4	nr Sorgho	37 43 38.3	87 16 50.5	37.72731	-87.28069	374	major tributary
Pond River	12	05110006	12.4	nr Sacramento	37 23 42	87 21 11.2	37.39500	-87.35311	523	hydrologic unit index site
Ohio River Tributaries										
Highland Creek	110	05140102	13.4	nr Smith Mills	37 45 24.8	87 47 42.0	37.75689	-87.79500	390	major tributary
Tradewater River										
Tradewater River	112	05140205	24.9	nr Piney	37 23 56.0	87 54 16.9	37.39889	-87.90469	619	hydrologic unit index site
Tennessee River										
Clarks River	106	06040006	14.3	nr Sharpe	36 58 18.5	88 30 53.9	36.97181	-88.51497	313	hydrologic unit index site
West Fork Clarks River	107	06040006	7.8	nr Symsonia	36 55 56.9	88 32 37.6	36.93247	-88.54378	187	major trib
Mississippi River										
Bayou de Chien	109	08010201	11.2	nr Moscow	36 36 54.8	89 01 48.4	36.61522	-89.03011	178	major tributary
Mayfield Creek	42	08010201	10.8	nr Magee Springs	36 55 47.6	88 56 34.7	36.92989	-88.94297	300	major tributary

Watershed Monitoring Assessment locations are generally at the downstream end of 5th order watersheds or near the downstream end of reference reach streams. Watershed Monitoring locations are selected after consultation with the Watershed Coordinator and river basin teams.

Lake Monitoring Assessment sampling sites are dependent on lake size. In small reservoirs and natural lakes one site is usually sufficient. This site is located just up stream of the dam at the deepest point in the lake. In larger reservoirs, additional sites may be located to sample water quality in embayment areas.

STEP 2. Preparation of a Sample Plan

A sample plan shall be prepared for each sampling location and shall contain the following components:

- 1. Objective(s)
- 2. Maps
- 3. Rationale
- 4. Requests for Analyses
- 5. Field Methods and Procedures
- 6. Health and Safety Plan
- 7. Data management

Water quality sampling is expensive and time consuming, so be certain before sampling begins that sample will serve project goals. The original sampling plan will be kept by the Water Quality Branch and a copy of the sampling plan will be sent to the Regional Office(s) conducting the sampling.

STEP 3. Location and Description of the Sampling Locations

The location and identification number of a water quality sampling station (monitoring point) should be accurately marked on a large-scale map as an X, circle or dot. This not only enables field personnel to easily find the stations, but also allows the data to be digitized into a computer database. As part of the station file, the following should be included:

- 1. Diagram depicting physical setting
- 2. Coordinates
- 3. Photographs
- 4. Driving routes to sampling stations

Determining Station Coordinates

Latitude and longitude are the coordinate pairs that are used to define location on a three-dimensional globe. These coordinate pairs are used in various databases to assign location of sampling points. Coordinates are to be read in decimal degrees (XX.XXXX/XXX.XXXX) as required in Database Recommendations for Location Version 1.0 (Kentucky Natural Resources and Environmental Protection Cabinet, Office of Information Services, no date). Latitude and longitude may be determined using either GPS (global positioning system) receivers, USGS maps or mapping software such as Arc View.

Photographing the Station

Photograph fixed-station sites on a regular basis for site documentation purposes. Take enough photos on the first visit to the site to establish a complete photo record of the site and its surroundings. (This also will assist a first-time visitor in locating the site.) After the first visit, take photos according to the procedures outlined below.

Take photos from established and constant photopoints. The preferred photopoint is a naturally occurring object, such as a large tree or boulder. For example, the photographer can put his or her back against a specific tree trunk to take one of the required photographs at each visit to the site. If naturally occurring landmarks are unavailable at a given site, try to mark the photopoint in some durable yet unobtrusive and temporary way, such as with a pile of rocks. At the first visit to the site, describe the photopoints in detail in the field notes. Record field notes in the site files as a permanent part of the file.

Include a person in the photo of the sample point to show scale. For a surface water station, take two photos using a digital camera from: 1) upstream of the sample point looking downstream at the sample point and 2) downstream of the sample point looking upstream at the sample point.

Take additional photos if you notice any significant change in the site area, such as severe channel scour, severe deposition, recent construction or other biological or ecological changes that warrant documentation. Emphasize in the photos those aspects that are likely to impact water quality.

Digital camera photos are to be accompanied by the following information: site ID, site name, date and time and the orientation of the photo. The Ambient Monitoring Coordinator will maintain diskettes on file.

On the last visit to a site, retake the same photos that were taken on the first visit (from the same photopoints) in order to document the changes that occurred over the lifetime of the site.

III. PREPARATION

STEP 1. Containers and Preservatives

Sample containers and preservatives can be replenished by e-mailing the Ambient Monitoring Coordinator. Allow one month for supplies to be delivered after sending e-mail. Labels, coolers and ice may be obtained from local vendors through use of a PRO-CARD. Field data sheets will be e-mailed to regional offices as updated. Copies of the field data sheets are to be reproduced at the regional offices. Table 2 lists containers and preservatives needed for analyses to be run on ambient/ watershed samples.

Table 2. Containers and preservatives needed for ambient/watershed Samples

Container Size, Type	Preservation Method	Variable Groups	Analysis Method(s)	Holding Time
1 liter, HDPE bottle	Cool to 4 degrees C	Bulk variables (TSS, Cl, SO4, Alkalinity, TOC)	EPA 160.2; ASTM (18 th) 4500-Cl B; EPA 375.1; EPA 310.1; EPA 415.1	TSS – 7 da; Alkalinity – 14 da; remainder 28 da
1 liter, HDPE bottle	H2SO4 < pH 2.0, Cool to 4 degrees C	Nutrients (ammonia-N; TKN-N; nitrite+nitrate-N; total phosphorous	EPA 350.1; EPA 351.2; EPA353.2; EPA 365.1	28 da
1 liter, HDPE bottle (pre-cleaned)	HNO3 < pH 2.0	Metals (calcium, iron, magnesium, potassium, sodium – ICP/AES; aluminum, arsenic, barium, cadmium, chromium, copper, lead, manganese, zinc – ICP/MS)	EPA methods 200.7 and 200.8; analysis methods vary by metal	6 mo
1 liter, amber glass bottle	5 ml conc. HCL, Cool to 4 degrees C	Low level Mercury	EPA 1631E	28 da
1 liter, amber glass bottle	Cool to 4 degrees C	N/P Pesticides Method 507 (e.g. atrazine, metribuzin, simazin)	EPA 507	7 da
1 liter, amber glass bottle	Cool to 4 degrees C	Pesticides Method 508 ¹ (e.g. organochlorine compounds, chlorpyrifos, endosulfan)	EPA 508	7 da
1 liter, amber glass bottle	Cool to 4 degrees C	Herbicides Method 515.3 (e.g. 2, 4-D)	EPA 515.3	7 da
125 ml, amber glass bottle	Cool to 4 degrees C, 4 ml monochloroacetic acid	Carbamates Method 531.1	EPA 531.1	28 da
125 ml, amber glass bottle	Cool to 4 degrees C	Glyphosate (Roundup)	EPA 547	18 months/frozen
120 ml, disposable coliform sample container	Cool to 4 degrees C; samples should arrive at lab within 6 hours (ideally) + 2 hour lab prep time (acceptable)	Fecal coliform bacteria	ASTM (19 th) 9222 D	8 hours maximum
Camera film container	Filter through .45 µ Whatman glass fiber filter, cool to 4 degrees C	Chlorophyll-a	ASTM (19 th) 10200H	3 weeks if frozen

¹Method 508 pesticides are normally taken from the Method 507 bottle; therefore, do not collect Method 508 samples in a separate bottle unless instructed.

STEP 2. Assembling and calibrating sampling equipment

Obtaining representative surface water samples commonly requires much (or many pieces of) equipment. Make sure you are prepared. This is especially important if the sampling site is far from the office, making it difficult to replenish supplies or pick up forgotten items. The checklist of supplies in Appendix B is a useful guide for many sampling projects.

Calibration of Field Meters

Field measurements are the determinations of physical properties or chemical constituents that are measured onsite, as close as possible in time and space to the media being sampled. Measurements of water temperature, pH, DO and specific conductance could change dramatically within a few minutes or hours after sample collection. Therefore, field measurements of these properties are required if representative results of in-stream conditions are to be obtained. Field measurements, field notes on sampling methods or equipment used, site observations and calibration information should be recorded on field forms for later reference. These field forms or notes may vary in format.

STEP 3. Cleaning Sampling Equipment

Equipment that makes contact with a water quality sample must be carefully cleaned before reuse. Examples are pump tubing, DH-81 samplers and mason jars. The following cleaning procedure has been adopted and modified from the USGS National Field Manual (op. cit.):

- 1. Wearing powder-free vinyl gloves, wash equipment with nonphosphate detergent.
- 2. Rinse with tap water to remove all soap residues. Follow with a rinse with deionized water (DIW).

NOTE: FOR EQUIPMENT USED EXCLUSIVELY FOR ORGANIC-COMPOUND PROCESSING, OMIT STEPS 3 AND 4.

- 3. Rinse with 5% hydrochloric acid solution.
- 4. Change gloves and rinse three times with DIW.

NOTE: IF ORGANIC-COMPOUND SAMPLES ARE NOT COLLECTED, OMIT STEPS 5 AND 6.

5. Rinse with minimal amount of pesticide-grade methanol.

- 6. Allow to air dry.
- 7. Protect cleaned equipment by placing in a clean ziplock bag for storage and transport.
- 8. Rinse sampling equipment at the site with native water before sampling.

If several sets of sampling equipment are available, decontamination can be performed in batches at the beginning or end of a sampling day. This saves time and reduces the number of field blanks necessary.

IV. SAMPLING

STEP 1. Health and Safety Guidelines

To ensure safety, fieldwork requires an awareness of potential hazards and knowledge of regulations and recommended procedures. The collection of water quality data in the field brings field personnel in touch with numerous hazards. Personnel routinely work in extreme environmental conditions and in remote locations. Winter weather conditions can present an especially hazardous time for water quality sampling. Roads are often icy and wind chills may be low enough to cause skin damage. Therefore, the following are strongly recommended. Do not make sampling trips when either travel advisories have been issued or the wind chill is minus 10 degrees F or lower. Two web sites, the Golden Gate Weather Services' New Wind Chill Temperature Formula (available online at http://www.ggweather.com/windchill.htm) and the Kentucky Transportation Cabinet's KY Direct 511 Traffic & Travel Info (available online at http://www.511.ky.gov/), may be especially useful for assessing winter weather conditions and driving advisories. Water quality studies involve the transportation and use of equipment and chemicals. Personnel routinely come in direct and indirect contact with waterborne and airborne chemicals and pathogens and with potentially dangerous animals and plants. General safety guidelines include:

- 1. Certification of samplers in first aid, CPR, bloodborne pathogens training and driver training. If an individual will be involved in towing trailers, trailer training is also required.
- 2. Conducting sampling from a boat requires at least two persons.
- 3. Determining the location of the nearest hospital, clinic or physician before sampling.
- 4. Receiving the appropriate immunizations. Vaccinations for tetanus, hepatitis A and B are recommended when working near contaminated waters.
- 5. Notifying others of your itinerary and whereabouts.
- 6. Taking precautions against hunters, poisonous snakes and sudden water rise.
- 7. Carrying identification.
- 8. Taking a cellular telephone on sampling trips.
- 9. Being aware of all bridge safety guidelines (Appendix A).

10. Wearing disposable, powderless gloves when handling sample preservations such as acid.

STEP 2. Field Measurements

Field measurements taken by the Kentucky Ambient/Watershed Monitoring Assessment program are performed using multimeters. Single variable (e.g. dissolved oxygen, specific conductance) meters are still used by a few regional offices. These older meters are being phased out and replaced by multimeters.

Before taking field measurements, sensors must be allowed to equilibrate to the temperature of the water being monitored. Allow at least 60 seconds (or follow the manufacturer guidelines) for sensors to equilibrate with sample water. Sensors have equilibrated adequately when temperature readings have stabilized. Field measurements should be made in-stream if possible (at the centroid of flow) if the stream appears to be completely mixed from bank to bank.

Appendix C presents QA/QC audit procedures for field meters.

Temperature

Field measurements should include both air temperature and water temperature. Air temperature is defined to be an observation and may be assessed from the air temperature given over the radio. Because of possible environmental contamination if broken, mercury-filled thermometers should not be used. Water temperatures should be determined using a thermistor, an electrical device made of a solid semiconductor that has a high temperature coefficient of resistivity. Thermistor calibration should be checked in the laboratory or office once a year using an American Society for Testing and Materials (ASTM) thermometer. Water temperatures should represent the mean temperature of the stream at the time of the observation. A horizontal and vertical crosssection profile will determine variability, if any. Streams with highly variable temperature profiles should have several readings averaged to use as the mean, and those variations should be documented. Streams with fairly uniform temperatures (less than 2° C variance 95 percent of the time) generally will have one measurement that can be made and reported as the stream temperature. In wadeable streams, stand so that a shadow is cast upon the site for the temperature measurement. Hold the thermistor or probe by its top and immerse it in the water. Allow it to stabilize for at least one minute, then read and record the temperature to the nearest 0.1° C without removing from the water.

When temperature cannot be measured in-stream, it should be measured in a 2-1/2-gallon bucket. The following conditions must be met when measuring temperature from a bucket.

• The bucket must be large enough to allow full immersion of the thermistor or probe. The bucket is to be rinsed with river water at each site prior to collecting sample.

- The thermistor or probe must be placed in the bucket immediately (not more than 5 minutes after water collection), before the temperature changes.
- The bucket must be shaded from direct sunlight and strong breezes before and during temperature measurement.
- The thermistor or probe must be allowed to equilibrate for at least 1 minute before temperature is recorded.

pН

Calibrate the pH sensor according to manufacturer directions. The pH function should be calibrated each day of use for multi-parameter instruments. To detect any drift in instrument reading during the course of sampling, post-calibration is recommended.

Preferably, pH is measured directly in-stream. Allow the pH probe to equilibrate for at least one minute before pH is recorded to the nearest 0.1 standard unit.

If pH cannot be measured in-stream, it should be measured in a bucket using the precautions outlined in the <u>Temperature</u> section.

Dissolved Oxygen

Dissolved oxygen (DO) is the oxygen freely available in water. DO is normally measured with a DO meter, preferably in place at the depth(s) specified earlier in this section. Refer to instrument manual for specific calibration requirements. The calibration value to be used when calibrating by the air saturation method can found in Appendix D.

Calibrate the DO sensor on the multi-parameter instrument. The DO probe must equilibrate for at least 90 seconds before DO is recorded to the nearest 0.1 mg/L. Care must be taken at profile stations to ensure that the reading is stable for each depth. Because DO takes the longest to stabilize, record this parameter after temperature, pH and specific conductance. When using the multimeter in waters flowing at less than one foot per second, it is recommended that the meter circulator be used to provide adequate flow for reliable dissolved oxygen readings. In waters having flows in excess of one foot per second, merely point the probe in the direction of the on-coming flow to obtain dissolved oxygen readings. To detect any drift in instrument readings during the course of sampling, post-calibration often is recommended.

If dissolved oxygen cannot be measured in-stream, it should be measured in a bucket using the precautions outlined in the <u>Temperature</u> section.

Specific Conductance

Preferably, specific conductance is measured directly in-stream at the depth(s) specified in this section. Calibrate the conductivity meter in the lab or field. Standards of known conductivity are required for calibration of multi-parameter instruments. Conductivity standards should be high enough to encompass expected stream measurements. This can

be obtained from historical data or general knowledge of an area. Allow the conductivity probe to equilibrate for at least one minute before specific conductance is recorded to three significant figures (if the value exceeds 100). The primary physical problem in using a specific conductance meter is entrapment of air in the conductivity probe chambers, which is indicated by unstable specific conductance values fluctuating to as much as $100~\mu\text{S/cm}$. The entrapment of air can be minimized by slowly, carefully placing the probe into the water; when the probe is completely submerged, move it through the water quickly to release any air bubbles. To detect any drift in instrument readings during the course of sampling, post-calibration often is recommended.

If specific conductance cannot be measured in-stream, it should be measured in a bucket using the precautions outlined in the <u>Temperature</u> section.

STEP 3. Collection of Representative River Water Samples

Preventing ambient water samples from becoming contaminated during the sampling and analytical process is one of the greatest challenges faced in the generation of water quality information. The Kentucky Ambient/Watershed Monitoring Assessment program contamination control policy is presented in Appendix E. Appendix F presents the quality control design for the program

The following sections provide a field reference for chain of custody procedures, sampling surface water and further procedures for measuring field variables and handling water quality samples.

A. Chain of Custody Procedures

The Ambient/Watershed Monitoring Chain of Custody form (Appendix G) serves to document and record the transfer of the samples from the water body to the laboratory, functions as a field measurement form and provides a place for field observations. Listed are data elements of the chain of custody.

Sample Identification

- Report Number and Laboratory Number this information is to be entered by laboratory
- Site Identification name of sample site
- Station number
- Name of county where collected
- Collection date/time

Field Measurements

- Field measurements temperature, specific conductance, pH, dissolved oxygen, turbidity, meter used and date calibrated
- Stage height or reference point measurement

Variables

- Sample matrix
- Container size and type
- Preservation including acid lot number
- Variables to be analyzed

Signatures

- Sampler's identification
- Relinquished by
- Samples received at laboratory by

Field observations

- Sampling location (bridge, in-stream or boat)
- Flow conditions
- Hydrologic condition
- Weather at time of sampling
- Weather in past 24 hours
- Stream mixing
- Stream color
- General observations
- Stream shading

B. River and Stream Sampling

Collect samples at the same bridge point or stream cross section throughout the period of record, if possible. This will eliminate many of the potential problems that might arise during the interpretation of the water quality data. This does not mean that the same section used during low-flow wading stage must be used during higher stages that require the use of a bridge. It is strongly recommended that, whenever possible, sampling be conducted by wading since this results in less chance of sample contamination, and it is safer. It is recommended that whenever possible, the field crew consist of two persons. It is felt that an additional crew member not only is more efficient, but is also a matter of safety. The decision whether to use two persons is at the discretion of the Division of Water field office supervisor.

In-stream sampling

Two sampling methods are available for in-stream sampling. These methods include direct grab sampling and the DH-81 sampler. Under most wading stage conditions, direct grab sampling will be employed. The DH-81 sampler is a depth-integrating sampler used when wading is possible but direct grab sampling is limited by stream depth. (For information regarding the DH-81 sampler visit the Federal Interagency Sedimentation

Project Internet page http://fisp.wes.army.mil/Catalog_Page_US_DH-81_Sampler.htm.) Disposable powderless latex gloves are to be worn when using either method.

In-stream sampling safety

A maximum safe wading depth depends on the size of the person sampling, the steram velocity and the streambed material. Each sampler should know and strictly adhere to hi/her personal wading limitations. Record stage heights/tapedown readings and whether stream was wadeable. Maintain in notebook for later reference when sampling. Caution should always be used when wading streams deeper than three feet. Additional caution should be used when the streambed is composed fo loose or slippery material. Algaecoated cobbles and bedrock can be slippery and dangerous as ice.

Sampling personnel should wear the following:

- Waders equipped with wading belt; waders should have felt soles to reduce slipping on stream bottoms
- USCG-approved Type-III floatation vest

In either method, the sampler approaches the stream from a downstream location, walking upstream to the sampling site. This is very important so as not to disturb bottom sediments that could contaminate the water quality sample. An ideal wading location is at the head of a riffle so that water current produces a good flow past the sampling point. First the sampler contaminates the gloves with stream water. Sample bottles are then contaminated with river water. Rinse pre-washed bottles (metals, pesticides and Mason jar used with DH-81 sampler) once with river water. Rinse bottles (bulk, nutrient), which have not been pre-cleaned, three times with river water. Whether using either the grab method or DH-81 sampler, the sample bottle is lowered from the surface to the bottom until the sample bottle touches the stream bottom. (When stream flow is low it is especially important to disturb bed sediments as little as possible.) Upon reaching the bottom, the sample bottle is raised to the surface. Try to approximate the same transit rate when lowering and raising the sampler. This action is repeated until the bottle is filled with stream water. Rinse the bottle cap in the stream and cap the bottle. At wadeable sites, water sample collection should be conducted in the centroid of flow if field measurements indicate the stream to be completely mixed from bank to bank. If field measurements do not indicate complete mixing, collect a composite sample at 1/4, 1/2 and 3/4 of the stream width.

Bridge sampling

Bridge sampling is recommended only when stream depths prevent in-stream sampling. Sampling from bridges not only increases danger to samplers, but also increases the potential of sample contamination from road dust and vehicle exhaust. It is essential that motorists be made aware of sampling activities. Protocol for installation of traffic control devices used in work zones is found in the <u>Guidelines for Traffic Control in Work Zones http://www.ktc.uky.edu/archive_T2/WZTCb.pdf</u> prepared by the University of Kentucky

Transportation Center in cooperation with the Kentucky Transportation Cabinet, Kentucky State Police and Federal Highway Administration.

Sampling personnel should wear the following:

• Orange safety vest

Protocol for sampling at bridge crossings is presented in Appendix A.

The weighted bottle sampler (WBS) is used when sampling off bridges. A single mid-channel sample is collected at bridge crossings. Ideally, a two-person crew should be employed. By utilizing two persons, the clean hands (CH)/dirty hands (DH) technique can be used. DH handles the WBS, raising and lowering it from the bridge. The DH never touches the sample bottle directly. CH is responsible for placing the bottle in the WBS and placing the cap on the bottle. CH is to wear powderless, latex gloves. CH should never touch the WBS or the bridge. If one person is using both the WBS and placing the caps on the sample bottles, multiple glove changes are required. After lowering and raising the WBS, a change of gloves is required for the single sampler technique before the sample bottle may again be handled.

Using either method, a sample bottle is lowered to the river and allowed to fill. Water collected is then used to fill and rinse the other sample bottles. Fill the other bottles about a quarter full with water. Cap, shake and discard rinse water. Recap until used. Place the cap face down in a ziplock bag while filling the sample bottles to reduce the chance of contaminating the cap with airborne pollutants.

To collect a water quality sample, place a capped bottle in the WBS. Whenever placing or removing a bottle from the WBS, recap bottle prior to swinging the WBS arm. This will prevent an inadvertent drop of water falling from the WBS arm into sample bottle. Lower the WBS holding bottle until it just reaches water surface. Allow current to carry the WBS downstream a little. Raise the WBS just above water's surface and allow it to swing under bridge. Release rope to lower WBS into water. Allow enough rope out so the WBS can touch bottom of stream directly under sampler. A little practice is needed, but this procedure can be done in a more or less fluid motion. Allow the current to carry the WBS downstream. When the WBS has stopped moving downstream, raise the sampler to the surface. Depending on the velocity of flow, it may take one to several times to fill bottle.

Gage height measurements

Gage height, or reference point measurements, are to be taken on each site visit. Discharge measurements will be conducted at various flows so that a rating curve can be developed. Recorded gage height measurements can be compared to the rating curve to determine stream discharge. Discharge information can then be used to calculate stream loading.

Gage height measurements are conducted at bridge crossings. Measurements are made using USGS wire-weight equipment where available.

At all bridge crossings at which wire-weight equipment is not available, tapedown measurements are required. At some point on the bridge, usually in mid-span on the downstream side of the bridge, a tapedown point is painted on the bridge. This point is painted on the first visit to the bridge. A chisel mark is also etched onto the bridge to facilitate locating the tapedown point in subsequent site visits. Tapedowns are made using a tape measure and an attached weight (i.e. gate hinge). When using either method, lower the weight until it barely touches the water surface. Record this value. When using the tapedown method, record the value in the following manner: tapedown distance + length of gate hinge. Tapedown measurements should be recorded in tenths of a foot.

Real-time gage heights can also be obtained for select USGS sites by going to the Internet at: http://water.usgs.gov/realtime.html.

Fecal coliform and Escherichia coli bacteria

Fecal coliform and *E. coli* bacteria are used to assess the quality of water because they are correlated to the presence of several waterborne disease-causing organisms (pathogens). The concentration of indicator bacteria (the term "indicator bacteria" is used synonymously with fecal coliform and *E. coli* indicator bacteria in this document) is a measure of public health safety for contact recreation or for consumption. The identification and enumeration of indicator bacteria measure the sanitary quality of water.

To collect samples for indicator bacteria in streams by wading, dip the sample container (sterile, unrinsed) to a depth of about 4 in. with the open end facing upstream. Push the mouth of the container upstream at this depth until the container is nearly full. The mouth of the container should at all times be upstream of the sample collector, sampling apparatus and any disturbed sediments. To collect samples for indicator bacteria in non-wadeable streams, attach sample container to a swivel attached to a fishing line. Lower the container from bridge to stream to collect sample. To collect samples for bacteria when using a boat, dip the container to a depth of about 4 in. The mouth of the container should be pushed at this depth away from the boat, sample collector, sampling apparatus and any disturbed sediment. Leave enough airspace (approximately 20%) in the top of the sample container to help mix the sample when it is shaken just before filtration. Bacteriological samples should be collected at the same locations as field measurements and water quality samples.

Always use a sterile container such as a disposable coliform sample bottle or a new Whirlpak bag to collect the sample. Immediately chill samples in an ice chest or refrigerator at 1° to 4° C. Do not freeze samples. Deliver samples to the laboratory as soon as possible, ideally within six hours from time of collection. However, as long as from sample collection time to placement of prepared samples in incubator occurs within eight hours, the sample results will be valid. Begin preparation and incubation as quickly

as possible, preferably within one hour, but the process cannot exceed eight hours after sample collection to minimize changes in indicator bacteria density.

Microbiological laboratory procedures may be found in Methods for Assessing Biological Integrity of Surface Waters in Kentucky (Kentucky Department for Environmental Protection, Division of Water, Ecological Support Section. *Methods for Assessing Biological Integrity of Surface Waters in Kentucky*. Frankfort, Kentucky, 2005).

Chlorophyll-a

Algae are responsive to changes in their physical environment. When particular conditions exist, such as extended photoperiod, low flow and high nutrient concentrations, algae reproduce rapidly creating nuisance growths or blooms. Trophic status of lakes and rivers may be based on chlorophyll-*a* levels. Chlorophyll-*a* is one approach used to estimate phytoplankton biomass. To gather information to determine the relationship between nutrient and phytoplankton biomass, chlorophyll-*a* concentrations are measured at selected large river ambient monitoring sites. A phytoplankton sample will also be collected to determine dominant "bloom" species.

Sampling Design Protocol

Definition of water quality variable: chlorophyll-a

Frequency of sampling: Sampling will be conducted monthly during the period May through October whenever stable, low-flow conditions exist and elevated dissolved oxygen (≥ 9 mg/L or $\geq 110\%$ saturation) and pH (≥ 8.0) are measured in the field, or greenish water color are met.

Chlorophyll-*a* **sampling locations:** Environmental conditions for the establishment of algal "blooms" are primarily met only in low-gradient riverine situations; sampling sites for chlorophyll-*a* are located at the lowest downstream ambient sampling sites in 8-digit hydrologic units

Collection of chlorophyll-a samples:

Grab Sample

Grab samples may be collected off a bridge. Samples are to be collected by submersing a 1-liter HDPE bottle to a depth of approximately 18 inches (roughly elbow length). Sample collection is similar to that method used for collecting euphotic zone samples in lakes or reservoirs.

Sample labeling: Chlorophyll-*a* samples are to be labeled with a waterproof permanent marker. The label should include stream name, date sampled and collector.

Sample shipping: Chlorophyll-a samples must be kept on ice and shipped overnight to:

Gillian Miller Division of Water Water Quality Branch 14 Reilly Road Frankfort, KY 40601

Sample processing: Upon receipt of chlorophyll-*a* samples by the Water Quality Branch, samples are either to be refrigerated at 4°C or filtered immediately. Samples may be held for up to 48 hours prior to filtering. Chlorophyll-*a* analysis should be performed within 30 days of sample collection.

STEP 4. Collection of Representative Lake/Reservoir Water Samples

NETWORK DESIGN

Kentucky lakes are currently sampled on a Watershed Management Framework Initiative approach. A total of 105 lakes that are listed in the Division of Water's lakes inventory are sampled every five years by basin management unit. Beginning in 1998, lakes have been sampled in order of basin management unit: 1) Kentucky River; 2) Salt and Licking Rivers; 3) Four Rivers (includes the Upper Cumberland, Lower Cumberland, Ohio, Mississippi and Tennessee rivers); 4) Green and Tradewater rivers; and 5) Big Sandy and Little Sandy rivers and Tygarts Creek. Ohio River minor tributary basins adjacent to the major river basins are sampled in the same year as the rest of the basin management unit.

LAKE SAMPLING AND ANALYTICAL METHODOLOGY

Sampling Locations

Sampling site locations (Table 3) for Division of Water inventory lakes were established in 1984. Sample sites always include the deepest part of the lake near the dam. Mid-lake and upper lake stations were established depending on lake size and purpose of study. Lakes with major tributaries have sampling stations located in the embayment to fully assess the total acreage of the lake.

Water quality monitoring stations for major reservoirs that are managed by the U.S. Army Corps of Engineers are located and sampled at historical sampling sites that have been established for each lake by the U.S. Army Corps of Engineers (COE).

Table 3. Kentucky clean lakes monitoring stations.

Watershed	Station name	STA#	HYDRO UNIT	LAT (+)	LONG (-)
Big Sandy	Fishtrap Lake - dam	138	05070202	37.43279	82.41643
	Fishtrap Lake - Grapevine Creek	139	05070202	37.42470	82.36890
	Fishtrap Lake - Lick Creek	140	05070202	37.40970	82.31170
	Dewey Lake - dam	135	05070203	37.73580	82.72720
	Dewey Lake - just upstream of Brandykeg Embayment	136	05070203	37.69908	82.72493
	Dewey Lake - confluence of Dicks Creek	137	05070203	37.69810	82.68220
	Paintsville Lake - dam	189	05070203	37.84137	82.87178
	Paintsville Lake - upstream of Low Gap Branch	190	05070203	37.88205	82.92733
	Paintsville Lake - downstream of Open Fork	191	05070203	37.89844	82.98633
	Carter Caves Lake near Olive Hill	062	05090103	38.36610	83.11860
	Yatesville lake - dam	193	05070204	38.12510	82.69730
	Yatesville Lake - upstream of San Branch	194	05070204	38.09137	82.71248
	Yatesville Lake - Brushy Creek	195	05070204	38.08924	82.74305
	Greenbo Lake - dam	063	05090104	38.49060	82.86720
	Greenbo lake - Claylick Creek Arm	064	05090104	38.48610	82.87440
	Greenbo Lake - Buffalo Branch Arm	065	05090104	38.84220	82.86970
	Grayson Lake - dam	212	05090104	38.25219	82.98513
	Grayson Lake - downstream of Clifty Creek	213	05090104	38.23390	83.00806
	Grayson Lake - upstream of Bowling Branch	214	05090104	38.19633	83.02999

Table 3 (cont.). Kentucky clean lakes monitoring stations.

Watershed	Station name	STA#	HYDRO UNIT	LAT (+)	LONG (-)
Licking	Williamstown Lake - Goose Creek Arm	041	05100101	38.66598	84.52822
	Williamstown Lake - SF Grassy Creek Arm	042	05100101	38.67634	84.53712
	AJ Jolly Lake - dam	043	05100101	38.87720	84.38560
	AJ Jolly Lake - upper lake	044	05100101	38.88500	84.36920
	Kincaid Lake - dam	045	05100101	38.72419	84.29052
	Kincaid lake - upstream of Turkey Branch	046	05100101	38.72190	84.27280
	Doe Run Lake near Erlanger	082	05100101	38.98692	84.55569
	Sand Lick Creek Lake near Wallingford	083	05100101	38.38607	83.61395
	Greenbriar Lake near Upper Spencer	047	05100101	38.01970	83.84780
	Cave Run Reservoir		05100101		
	Lake Carnico near Carlisle	084	05100102	38.34670	84.04170
Kentucky	Fishpond Lake near Payne Gap	058	05100201	37.15750	82.67890
	Pan Bowl Lake near Jackson	059	05100201	37.56816	83.38160
	Buckhorn Lake - dam	106	05100202	37.33830	83.47110
	Buckhorn Lake - upstream of Rush Creek	107	05100202	37.27399	83.44329
	Buckhorn Lake - downstream of Wilder Branch	108	05100202	37.26979	83.37925
	Bert Combs Lake near Manchester	086	05100203	37.16670	83.70750
	Mill Creek Lake near Slade	060	05100204	37.76701	83.67319

Table 3 (cont.). Kentucky clean lakes monitoring stations.

Watershed	Station name	STA#	HYDRO UNIT	LAT	LONG
Kentucky (cont.)	Elmer Davis Lake near Owenton	035	05100205	(+) 38.49539	(-) 84.88201
	Bullock Penn Lake - dam	036	05100205	38.78920	84.65670
	Bullock Penn Lake - downstream of KY 491	037	05100205	38.79780	84.64390
	Boltz Lake near Dry Ridge	038	05100205	38.70580	84.61889
	Corinth Lake near Corinth	039	05100205	38.50440	84.58870
	Stanford Reservoir near Standford	085	05100205	37.48690	84.67860
	Herrington Lake - dam	091	05100205	37.77810	84.71140
	Herrington Lake - Chimney Rock	092	05100205	37.74890	84.70530
	Herrington Lake - Sims Boat Dock	093	05100205	37.71780	84.74170
	Herrington Lake - downstream of Chenault Bridge	094	05100205	37.67140	84.69000
	Lake Reba near Richmond	178	05100205	37.74110	84.25190
	Cedar Creek Lake near Crab Orchard	211	05100205	37.49567	84.55200
Salt	Lake Jericho near	080	05140101	38.44530	85.28140
	Reformatory Lake near Buckner	034	05140101	38.39986	85.43966
	Guist Creek Lake – dam	030	05140102	38.20810	85.15720
	Guist Creek Lake - Tick Creek Arm	031	05140102	38.20670	85.14110
	Guist Creek Lake - upstream of KY 1779	032	05140102	38.22080	85.14920
	Shelby Lake near Shelbyville	078	05140102	38.23060	85.22080
	McNeely Lake near Okolona	033	05140102	38.09810	85.63580
	Long Run Lake near Eastwood	079	05140102	38.26640	85.41750
	Marion Co. Sportman Lake near Calvery	024	05140103	37.51327	85.24788

Table 3 (cont.). Kentucky clean lakes monitoring stations.

Watershed	Station name	STA#	HYDRO UNIT	LAT (+)	LONG (-)
Salt (cont.)	Sympson Lake near Bardstown	025	05140103	37.80750	85.51030
	Willisburg Lake near Willisburg	026	05140103	37.82756	85.16260
	Beaver Lake - dam	027	05140103	37.96250	85.02220
	Beaver Lake - Beaver Creek Arm	028	05140103	37.97190	85.1560
Green	Campbellsville City Lake at Campbellsville	007	05110001	37.35750	85.34140
	Spurlington Lake near Spurlington	800	05110001	38.38500	85.25530
	Salem Lake near Hodgenville	010	05110001	37.58940	85.71140
	Shanty Hollow Lake near Genmore	023	05110001	37.15530	86.39000
	Metcalfe Co. Lake near Edmonton	089	05110001	37.04359	85.60996
	Liberty Lake near Liberty	090	05110001	37.32103	84.89466
	Freeman Lake near Elizabethtown	009	05110001	37.71560	85.86920
	Mill Creek Lake near Tompkinsville	088	05110002	36.68250	85.70080
	Spa Lake near Spa	005	05110003	36.94980	87.02954
	Lake Malone - dam	019	05110003	37.08080	87.03330
	Lake Malone - Clifty Creek Arm	020	05110003	37.05080	87.03940
	Lake Malone - Sulphur Spring Arm	021	05110003	37.06586	87.06252
	Luzerne Lake near Greenville	022	05110003	37.21280	87.19690
	Briggs Lake near Russellville	071	05110003	36.88780	86.83280
	Washburn Lake near Dukehurst	076	05110004	37.51810	86.84890
	Grapevine Lake near Madisonville	016	05110006	37.30530	87.47670

Table 3 (cont.). Kentucky clean lakes monitoring stations.

Watershed	Station name	STA#	HYDRO UNIT	LAT (+)	LONG (-)
Green (cont.)	Lake Beshear - dam	011	05140205	37.14810	87.68202
	Lake Beshear - Clifty Creek Arm	012	05140205	37.13330	87.67530
	Lake Beshear - Piney Creek Arm	013	05140205	37.12810	87.69860
	Loch Mary near Earlington	014	05140205	37.27330	87.52030
	(New) Providence City Lake near Providence	072	05140205	37.37497	87.79705
	Moffit Lake near Pride	073	05140205	37.57860	87.85470
	Carpenter Lake near Maceo	018	05140201	37.84560	86.98140
	Kingfisher Lake near Maceo	075	05140201	37.84470	86.97690
	Mauzy Lake near Boxville	017	05140202	37.62220	87.85580
	Scenic Lake near Henderson	074	05140202	37.87830	87.56190
	Lake George near Marion	004	05140203	37.30304	88.09060
Cumberland	Corbin Reservoir - dam	052	05130101	36.97073	84.12002
	Corbin Reservoir - upper lake	053	05130101	36.99251	84.12050
	Chenoa Lake near Chenoa	055	05130101	36.67640	83.85060
	Cannon Creek Lake near Ferndale	056	05130101	36.68050	83.69390
	Cranks Creek Lake near Smith	057	05130101	36.73830	83.23750
	Laurel Creek Lake near Whitley City	087	05130101	36.68940	84.44310
	Lake Linville near Renfro Valley	049	05130102	37.38610	84.34030
	Wood Creek Lake - dam	050	05130102	37.21280	84.19830

Table 3 (cont.). Kentucky clean lakes monitoring stations.

Watershed	Station name		HYDRO	LAT	LONG
		STA#	UNIT	(+)	(-)
Cumberland (cont.)	Wood Creek Lake - at boat dock	051	05130102	37.18670	84.17690
	Tyner Lake near Tyner	054	05130102	37.37853	83.91289
	Energy Lake near Golden Pond	001	05130205	36.86170	88.01530
	Lake Blythe near Hopkinsville	069	05130205	36.92310	87.49640
	Lake Morris near Hopkinsville	070	05130205	36.92030	87.45580
Four Rivers	Turner Lake near Oscar	067	05140206	37.17610	89.03970
	Metropolis Lake near Grahamville	121	05140206	37.14780	88.76670
	Swan Pond Lake near East Cairo	124	08010100	37.01338	89.11803
Discontinued	Campton Lake near Campton	061	05100204	37.74500	83.54690
due to access	Flat Lake near Barlow	066	08010100	37.04030	89.09920
or restrictions.	Caneyville Lake near Caneyville	077	05110004	37.43931	86.46386
	Owsley Fork Lake near Berea	209	05100205	37.54558	84.18237

Sampling Frequency

Lake sampling for trophic status determination is conducted three times during the growing season (April – October).

Sample Collection Methodology

- 1. A 3-liter non-metallic Kemmerer sampler and 12-liter Nalgene nonporous plastic sample containers are used to collect and composite lake samples. The Nalgene container and the Kemmerer sampler are thoroughly pre-cleaned and rinsed in the laboratory before going to the field. The Nalgene sample container and the Kemmerer sampler are both field rinsed with the lake water before collecting samples.
- 2. At time of sample collection, station header information is entered in waterproof ink or pencil on the Lake Data Sheet (Appendix H). Station header information includes: STORET number, lake name, date, time and station site name. Lake conditions and field observations should be entered in the space reserved for notes.
- 3. Containers, preservation techniques and holding times for eutrophication lake samples are listed in Table 2.
- 4. Alkalinity, nutrients and chlorophyll-a variables are analyzed in composite samples. The composite sample is based on the depth of the euphotic zone. The euphotic zone (depth of 1% surface illumination) is measured at each station during each sampling period using a submersible photometer. When the depth of the euphotic zone is determined, samples are collected by submersing the non-metallic Kemmerer sampler at the surface and at evenly spaced one meter intervals throughout the euphotic zone. Water samples are then collected at each depth and combined so that a euphotic zone composite sample is obtained.

Field Processing of Samples

- 1. Duplicate samples for chlorophyll-*a* analyses are filtered in the field. Filtering is conducted using 24 mm diameter, Whatman GF/C glass fiber filters and a calibrated 50-milliliter (mL) calibrated pipet. A 50-mL volume of sample is generally adequate for most lakes to tint the glass fiber filter paper with a greenish or brownish color. Sometimes a 100-mL volume is necessary in oligotrophic waters. The glass fiber filters from the field filtration are sealed in opaque camera film containers separated by aluminum foil, placed on wet ice and returned to the laboratory where they are frozen until analyzed.
- 2. Water samples to be analyzed for dissolved organic carbon, total soluble (total dissolved) phosphorus and soluble reactive orthophosphate are filtered in the field. A Gelman GN-6 Metricel filter (0.45 micron, 47-mm diameter) and a calibrated magnetic funnel are used to filter an aliquot of the composite sample. The sample is then placed in a 30-mL round Nalgene bottle for total dissolved phosphorus and

- soluble reactive phosphorus (orthophosphate) and a 60-mL square Nalgene bottle for dissolved organic carbon. The samples are preserved on wet ice and returned to the laboratory.
- 3. Sample cubitainers are rinsed with composite sample before filling. The outside of the cubitainer is marked with a waterproof marker with station Clean Lakes Number (CLN), station location description, station letter for multiple lake stations, time, date, parameters to be analyzed and the initials of the collectors. Samples are then preserved with appropriate acids and placed on wet ice.

Field Measurements

- 1. Water temperature, pH, dissolved oxygen and specific conductance are measured at the surface and then one-meter depth intervals to a depth of 20 m and then to approximately ½ meter from the bottom in five-meter intervals. A multiparameter probe with a 50 m cable is used in measuring these variables by lowering the sonde unit to the desired depths. Temperature (°C), pH SU (standard units), dissolved oxygen (mg/L) and specific conductance μS/cm) are recorded directly from the meter readings and entered on the Lake Data Sheet.
- 2. Visibility or visible light penetration is determined using a Secchi disk and "aquascope" viewer. The Secchi disk is submersed to point of disappearance on the shady side of the boat. This depth is noted. The disk is lowered a few feet more, then slowly raised until it reappears. This depth is noted. The average of these two readings is taken for the final Secchi disk visibility depth and estimated to the nearest 0.1 foot and later converted into meters.
- 3. Euphotic zone depth is determined by using a Protomatic or Licor LI-185b Underwater Photometer. On the sunny side of the boat, the photometer probe is lowered just below the water surface. Note reading. Calculate 1% of this value (depth of euphotic zone) and adjust meter to range in which the calculated value lies. The photometer probe is lowered to the depth at which the meter gives the calculated value. Depth of probe in meters and tenths of meters and light intensity in footcandles are recorded on the field sheet.

STEP 5. Preservation

Sample preservation is the measure or measures taken to prevent reduction or loss of water quality variables of interest. Variable loss can occur between sample collection and laboratory analysis because of physical, chemical and biological processes that result in chemical precipitation, adsorption, oxidation, reduction, ion exchange, degassing or degradation. Preservation stabilizes variable concentrations for a limited period of time. Some samples have a very short holding time. Verify that time-dependent samples were received in proper condition, at the correct temperature and that holding times were not exceeded.

Before going into the field:

- 1. Check sample requirements for chilling and chemical treatment.
- 2. Check with the laboratory and make note of holding times.

Chilling

Immediately following sample collection and processing, samples that require chilling must be packed in ice or placed in a refrigerator and maintained at 4° C plus or minus 2° C, without freezing, until analyzed.

- Check that there is sufficient headspace in the sample bottle to allow for sample expansion.
- Put foam sleeves or bubble wrap around samples in glass bottles before packing them in ice.

Chemical Treatment (Preservation)

Chemical treatment may be either conducted at each site, at the last sampling site of the day or on the day of collection in the office prior to shipment. The two latter approaches are recommended since it requires setup of a preservation chamber only once¹. Additionally, preservation at the lab either under a lab hood or field preservation chamber eliminates chance of windblown particles contaminating samples.

Chemicals used for sample preservation depend on the target variable. The most frequently used chemical preservatives by the Kentucky Ambient/Watershed Monitoring Assessment are provided in individual vialservatives and contain one of the following: nitric acid (HNO₃), sulfuric acid (H₂SO₄), hydrochloric acid (HCL) or monochloroacetic acid potassium acetate buffer. Sample preservation, along with sample designations and container requirements, are listed on the chain of custody. The preservatives are procured from the Ambient Monitoring Coordinator. Take steps to minimize sample contamination and maximize safety during the preservation process. Note that a chemical preservative for one sample may be a source of contamination for another. It is recommended that in order to help reduce contamination during the preservation process and ensure proper handling of chemicals:

- Work inside a preservation chamber (only the Clean Hands person works inside the chamber). Change gloves each time a different type of chemical treatment is used. Clean Hands/Dirty Hands techniques must be used for parts-per-billion levels of trace metals and are recommended for use in general and as appropriate for the study.
- Use preservatives packaged in individual vialservatives for routine preservation. Be aware that preservatives dispersed from dropper-type bottles or automatic pipettes

-

¹ The use of preservation chambers reduces the possibility of contamination and is required during sample preservation. These chambers are handmade. Generally a 2- by 2-ft frame is constructed using 1/4-in. PVC pipe to support a clear plastic bag, which forms a protective tent to work inside when preserving samples.

could become contaminated and could result in the contamination of subsequent samples.

- Use the grade of preservative appropriate to meet data-quality requirements.
- Always store preservatives in separate, sealed containers, preferably away from each other and away from environmental and quality-control samples.
- Follow a prescribed order in which samples are to be preserved (the recommended order is described in the steps below).
 - 1. Put on disposable, powderless gloves.
 - 2. Set up preservation chambers and assemble equipment and solutions in order in which they are used.
 - 3. Acidify samples in following order:
 - Nutrients sulfuric acid (1mL 1:1/liter)
 - Metals nitric acid (2mL 1:1/liter)
 - Low level Hg hydrochloric acid (5mL conc./liter)
 - N-methylcarbamates (Pesticides method 531.1) monochloroacetic acid
 - 4. Tighten cap on sample bottle immediately after adding acid and invert five times to mix.
 - 5. Disassemble the chamber frame.

STEP 6. Handling and Packing of Samples

Samples should be packaged and shipped to DES for analysis as soon as possible. Generally, the shorter the time between sample collection/processing and sample analysis, the more reliable the analytical results will be. Before shipping to the laboratory:

- Check that sample bottles are labeled correctly.
- Complete chain of custody form fully completing all required information.
- Pack samples carefully in the shipping container to prevent bottle breakage, shipping container leakage and sample degradation. Check that bottle caps are securely tightened (don't over tighten though).

A summary of procedures for shipping samples to DES is outlined below.

Labeling sample bottles

Each sample bottle must be correctly labeled with the station identification number, date, time and sample group.

• Label each bottle with preprinted labels that will remain securely attached to the bottles even if they become wet. Use a permanent, waterproof marker to enter information on label. Eagle-Picher labels have been found to remain attached to plastic bottles under wet conditions. However, these labels will come off glass bottles

when wet. Always attach labels prior to collecting samples. For glass bottles, after attaching labels, wrap clear shipping tape completely around bottle covering label.

- Write legibly and include as a minimum the following information:
 - 1. Station identification number
 - 2. Date and time of collection
 - 3. Sample group (bulk, nutrient, metals, 507/508, and so on)
 - 4. Initials of person collecting samples

Packing samples

When packaging samples for shipment to DES, remember that all bottles must be protected from breaking and leaking. DES will return the cooler.

When packaging samples:

- Make sure bottle labels are waterproof and that information is legible.
- Tighten all bottle caps to prevent leakage.
- Double bag coolers using large size garbage bags. It is recommended that 40 45 gallon bags, 1.5 ml or more in thickness, be used in lining coolers.
- Use adequate packaging material to prevent leakage.
 - 1. Ship all glass bottles in foam sleeves or wrap them in bubble wrap.
 - 2. Pack glass bottles so they touch each other as little as possible.
 - 3. Place each sample bottle in a separate zip-lock bag.
- Pack samples designated for chilling in coolers.
 - 1. Use insulated ice coolers. Do not use broken or leaky coolers.
 - 2. Pack samples designated for chilling with loose ice. **Do not use milk jugs with frozen water.**
 - 3. The volume of ice should be equal to or greater than the volume occupied by samples (twice the volume of ice is recommended during warm weather).
 - 4. The amount of ice necessary will vary depending on the length of time in transit and ambient air temperature. Chilling the cooler and samples prior to shipment is recommended during hot weather.
 - 5. Do not use blue ice or other types of commercial refreezing containers that have freezing points below 0°C. This can cause bottles to freeze and result in ruined samples or broken bottles.
 - 6. Seal cooler spouts or drains with silicone or epoxy.
- After samples and ice are placed in doubled plastic bags, close each bag separately with a knot.
- Inside coolers:
 - 1. Place chain of custody in ziplock bag. Affix ziplock bag to underside of the cooler lid.
 - 2. Label the inside of each cooler lid with the current return address and telephone number, using a permanent waterproof marker.

V. Data Management

Consistent data entry on the AMBIENT/WATERSHED MONITORING, CHAIN OF CUSTODY form and LAKE DATA SHEET is essential. This information serves as the basis for electronic entry of the data into the Division of Environmental Services (DES) database and the STORET database.

The most critical information for proper sample identification is the station ID, date and time of sampling, sample matrix and type of analysis requested (i.e. bulk, nutrient, metals, etc.)

All routine QC samples should be associated with an environmental sample. Do not use fictitious station ID numbers for routine QC samples.

The Water Quality Branch will enter field and bacteria data. All field and DES laboratory results are to be entered into the national STORET database within one year of collection.

Appendix A Traffic Control at Bridge Crossings

Traffic Control at Bridge Crossings

It is recognized that bridge sampling places field personnel in a potential high-risk environment and should not be taken lightly. Establishment of work zones at bridge crossings was strongly recommended. Procedures for installation of traffic control devices used in work zones listed in the SOP were taken from the <u>Guidelines for Traffic Control in Work Zones http://www.ktc.uky.edu/archive_T2/WZTCb.pdf</u> (see page 29) prepared by the University of Kentucky Transportation Center in cooperation with the Kentucky Transportation Cabinet, Kentucky State Police and Federal Highway Administration. The section on traffic control in the Kentucky SOP was designed to reflect that used by the USGS.

Fundamental principles in the SOP:

- 1. Ideally, do not locate sampling sites on high volume highways.
- 2. Traffic movement should be inhibited as little as practicable.
- 3. Motorists should be guided in a clear and positive manner while approaching and traversing temporary traffic control areas. The total traffic control system must meet three requirements:
 - Provide drivers advance warning;
 - Make the work area visible; and
 - Direct traffic around the work area.
- 4. All traffic control devices shall be removed immediately when not in use.
- 5. Only those who are trained in safe traffic control practices shall supervise the placement of traffic control devices in temporary work areas.

The SOP listed the following mandatory traffic devices:

- 1. orange reflective vest
- 2. minimum of four cones
- 3. warning signs (2) with the warning "BRIDGE WORK AHEAD"
- 4. vehicle roof strobe yellow light

At all sites where bridge sampling is required due to high flows or stream depth presenting unsafe wading conditions, it is recommended that traffic control be instituted following page 21 of the <u>Guidelines for Traffic Control in Work Zones</u>. This page presents guidelines for shoulder work with minor encroachment. This protocol modification replaces the existing protocol in the 2002 <u>Kentucky Ambient/Watershed</u> Water Quality Monitoring Standard Operating Procedure Manual.

Points of emphasis are listed below (not necessarily listed in importance):

- 1. Proper safety equipment must be available for samplers at each regional office.
- 2. Sampling plans must be prepared for all sampling locations where bridge sampling will be conducted.
- 3. Existing safety devices must be maintained.
- 4. Regional personnel must be trained in proper sampling safety.

Protocol for sampling at bridge crossings


- 1. All field personnel shall wear orange safety vests. Prepare all bottles and other sampling gear prior to moving onto bridge. Stay on bridge no longer than necessary to collect samples.
- 2. Place strobe light on roof of vehicle and turn on. Turn on headlights and emergency lights.
- 3. Set up warning signs to indicate to both lanes of traffic that work activity is being conducted on bridge. Signs should be set back from the roadway between 6 to 12 feet. It may be necessary to weight signs down with bags of sand to prevent blowing over by high winds or vehicular traffic.
- 4. Set up cones, establishing taper and work zones.
- 5. Work as efficiently as possible following manual protocol. When sampling is completed, remove cones.
- 6. When sample handling is completed, dismantle warning signs. Remove strobe light from vehicle roof.

Table A-1. General guidelines for work zone approach and taper zone lengths on two-lane roads.

Speed Limit (MPH)	Approach (feet)	Taper (feet)
25 and Below	200	70
26-35	200	130
36-40	200	160
45	350	280
55	500	330

Shoulder Work with Minor Encroachment (TA-6)

All lanes should be a minimum of 10 feet in width as measured to the near face of the channelizing devices. The treatment shown should be used on a minor road having low speeds. For higher-speed traffic conditions, a lane closure should be used. Although vehicle hazard warning signals can be used to supplement the rotating lights or strobe lights, they shall not be used instead of rotating lights or strobe lights.



Appenpdix B Water Sampling Supplies Checklist

Water Sampling Supplies Checklist

Field Survival
☐ Map of station locations
Business card or ID
Authorization (letter, etc.)
Field notebook
☐ Waterproof pens, markers and pencils
☐ Trip routing forms
Road log
Photo log forms
Field data forms
Chain of custody forms
Keys or security codes for gates and locks
☐ WD-40 for locks
First aid kit, knife
☐ Insect repellent (wash hands thoroughly after applying)
Hat, sunscreen, drinking water
Sunglasses or safety glasses
Leather gloves
Waders
Rain gear
Toolbox with basic tools
Tape measure
Flashlight and extra batteries
2-way radio/cellular phone
Weather radio
Uniform
Rope
Fire extinguisher (type B)
Physical Positioning
Camera, film
Site map
Global positioning system (optional)

Field Parameter Measurement
☐ Tape measure
☐ Calculator
Non-mercuric thermometers (2)
pH meter and buffers, pH indicator strips
☐ Temperature, Conductivity, Redox, Dissolved Oxygen meters, probes and batteries
Multimeter
Copies of manufacturers' manuals for field equipment
Surface Water
Coolers
Sample containers as required by sampling plan
Bags of ice
Field preservation chamber frame and garbage bags
1-gallon ziplock bags
Garbage bags for lining coolers
Paper towels, KIM-wipes
Acid preservatives (i.e. HNO ₃ , H2SO ₄ , HCL)
☐ VOA vials (for volatile organics)
Whatman glass fiber lifters for chlorophyll-a filtering
Disposable powder-free latex gloves
Microbial Sampling
Sterilized Whirl-pak bags or sterile plastic bottles (for fecal coliform and E. Coli samples)

Appendix C Field Meter Audit

Field Meter Audit

Field meter audits are a quality assurance procedure to ensure that field meters are both working and calibrating properly; thus, providing water quality data of integrity. Audits will be conducted twice yearly - once in the spring and again in the fall. Specific conductance and pH probes (meters) will be evaluated during the audit.

Audit procedure

At the time of the audit, unknowns for pH and specific conductance will be sent to the regional offices and others wishing to participate in the audit. The unknowns will consist of two one-liter bottles. One bottle is to be used for the pH audit; the other for the specific conductance audit. After allowing the unknowns to come to room temperature, water from the bottles is measured for pH and specific conductance. The results are entered in the form below and e-mailed to the Ambient Monitoring Coordinator. After all results have been received, the measurements will be evaluated for precision.

Source of unknowns

Unknowns will come from samples of native stream water. Sources will come from a variety of sites across the state. The sample water will be collected and then filtered through a 0.45-micron filter. The water will be filtered directly into the bottles to be sent to the regional offices.

Audit precision

Upon receiving all results, the relative precision of the results will be determined. Since the true value of the sample will never be known, the average of all results will be assumed the true value.

Percent relative error = $\underline{\text{(True value - measured value)}}$ X 100 True value

The results will also be evaluated to see if they differ from the expected value. This is a test to see if results fall within a certain confidence level. For the purposes of the meter audit a confidence level of 95% has been chosen.

Mean (±) of all results as determined: Student t variate X standard deviation/number of samples. If a result falls within the confidence level interval, the result is accepted as valid.

Reporting of Audit results

Results will be forwarded to individuals participating in a prompt manner, along with corrective measures if needed.

Appendix D

Tables for Dissolved Oxygen Concentration, Oxygen Solubility in Water, and Correction Factor for Oxygen Saturation at Altitude

TABLE D-1. KENTUCKY DIVISION OF WATER SATURATION CONCENTRATION OF DISSOLVED OXYGEN BY ELEVATION

ELEVATION = 300												
<u>TEMP</u>	<u>X.1</u>	<u>X.2</u>	<u>X.3</u>	<u>X.4</u>	<u>X.5</u>	<u>X.6</u>	<u>X.7</u>	<u>X.8</u>	<u>X.9</u>	<u>X.10</u>		
0	14.49	14.44	14.40	14.36	14.32	14.28	14.25	14.21	14.17	14.13		
1	14.09	14.05	14.01	13.97	13.93	13.90	13.86	13.82	13.78	13.74		
2	13.71	13.67	13.63	13.59	13.56	13.52	13.48	13.45	13.41	13.38		
3	13.34	13.30	13.27	13.23	13.20	13.16	13.13	13.09	13.06	13.02		
4	12.99	12.95	12.92	12.88	12.85	12.82	12.78	12.75	12.71	12.68		
5	12.65	12.61	12.58	12.55	12.52	12.48	12.45	12.42	12.39	12.35		
6	12.32	12.29	12.26	12.23	12.20	12.17	12.13	12.10	12.07	12.04		
7	12.01	11.98	11.95	11.92	11.89	11.86	11.83	11.80	11.77	11.74		
8	11.71	11.68	11.65	11.62	11.59	11.57	11.54	11.51	11.48	11.45		
9	11.42	11.40	11.37	11.34	11.31	11.28	11.26	11.23	11.20	11.17		
10	11.15	11.12	11.09	11.07	11.04	11.01	10.99	10.96	10.93	10.91		
11	10.88	10.86	10.83	10.81	10.78	10.75	10.73	10.70	10.68	10.65		
12	10.63	10.60	10.58	10.55	10.53	10.51	10.48	10.46	10.43	10.41		
13	10.38	10.36	10.34	10.31	10.29	10.27	10.24	10.22	10.20	10.17		
14	10.15	10.13	10.11	10.08	10.06	10.04	10.01	9.99	9.97	9.95		
15	9.93	9.90	9.88	9.86	9.84	9.82	9.80	9.77	9.75	9.73		
16	9.71	9.69	9.67	9.65	9.63	9.61	9.58	9.56	9.54	9.52		
17	9.50	9.48	9.46	9.44	9.42	9.40	9.38	9.36	9.34	9.32		
18	9.30	9.28	9.26	9.24	9.23	9.21	9.19	9.17	9.15	9.13		
19	9.11	9.09	9.07	9.05	9.04	9.02	9.00	8.98	8.96	8.94		
20	8.93	8.91	8.89	8.87	8.85	8.84	8.82	8.80	8.78	8.77		
21	8.75	8.73	8.71	8.70	8.68	8.66	8.64	8.63	8.61	8.59		
22	8.58	8.56	8.54	8.52	8.51	8.49	8.47	8.46	8.44	8.43		
23	8.41	8.39	8.38	8.36	8.34	8.33	8.31	8.30	8.28	8.26		
24	8.25	8.23	8.22	8.20	8.18	8.17	8.15	8.14	8.12	8.11		
25	8.09	8.07	8.06	8.04	8.03	8.01	8.00	7.98	7.97	7.95		
26	7.97	7.95	7.94	7.92	7.91	7.89	7.88	7.86	7.85	7.83		
27	7.82	7.80	7.79	7.77	7.76	7.74	7.73	7.71	7.70	7.68		
28	7.67	7.66	7.64	7.63	7.61	7.60	7.58	7.57	7.56	7.54		
29	7.53	7.51	7.50	7.48	7.47	7.46	7.44	7.43	7.41	7.40		
30	7.39	7.37	7.36	7.34	7.33	7.32	7.30	7.29	7.28	7.26		

				<u>ELEV</u>	ATION = 40	<u>00</u>				
<u>TEMP</u>	<u>X.1</u>	<u>X.2</u>	<u>X.3</u>	<u>X.4</u>	<u>X.5</u>	<u>X.6</u>	<u>X.7</u>	<u>X.8</u>	<u>X.9</u>	<u>X.10</u>
0	14.43	14.39	14.35	14.31	14.27	14.23	14.19	14.15	14.11	14.07
1	14.03	14.00	13.96	13.92	13.88	13.84	13.80	13.77	13.73	13.69
2	13.65	13.62	13.58	13.54	13.51	13.47	13.43	13.40	13.36	13.33
3	13.29	13.25	13.22	13.18	13.15	13.11	13.08	13.04	13.01	12.97
4	12.94	12.90	12.87	12.84	12.80	12.77	12.73	12.70	12.67	12.63
5	12.60	12.57	12.53	12.50	12.47	12.44	12.40	12.37	12.34	12.31
6	12.28	12.25	12.21	12.18	12.15	12.12	12.09	12.06	12.03	12.00
7	11.97	11.94	11.91	11.88	11.85	11.82	11.79	11.76	11.73	11.70
8	11.67	11.64	11.61	11.58	11.55	11.52	11.49	11.47	11.44	11.41
9	11.38	11.35	11.33	11.30	11.27	11.24	11.22	11.19	11.16	11.13
10	11.11	11.08	11.05	11.03	11.00	10.97	10.95	10.92	10.89	10.87
11	10.84	10.82	10.79	10.77	10.74	10.72	10.69	10.66	10.64	10.61
12	10.59	10.57	10.54	10.52	10.49	10.47	10.44	10.42	10.39	10.37
13	10.35	10.32	10.30	10.28	10.25	10.23	10.21	10.18	10.16	10.14
14	10.11	10.09	10.07	10.05	10.02	10.00	9.98	9.96	9.93	9.91
15	9.89	9.87	9.85	9.82	9.80	9.78	9.76	9.74	9.72	9.70
16	9.68	9.65	9.63	9.61	9.59	9.57	9.55	9.53	9.51	9.49
17	9.47	9.45	9.42	9.41	9.39	9.37	9.35	9.33	9.31	9.29
18	9.27	9.25	9.23	9.21	9.19	9.17	9.15	9.14	9.12	9.10
19	9.08	9.06	9.04	9.02	9.00	8.99	8.97	8.95	8.93	8.91
20	8.89	8.88	8.86	8.84	8.82	8.80	8.79	8.77	8.75	8.73
21	8.72	8.70	8.68	8.66	8.65	8.63	8.61	8.60	8.58	8.56
22	8.55	8.53	8.51	8.49	8.48	8.46	8.44	8.43	8.41	8.40
23	8.38	8.36	8.35	8.33	8.31	8.30	8.28	8.27	8.25	8.23
24	8.22	8.20	8.19	8.17	8.16	8.14	8.12	8.11	8.09	8.08
25	8.06	8.05	8.03	8.02	8.00	7.99	7.97	7.96	7.94	7.93
26	7.94	7.92	7.91	7.89	7.88	7.86	7.85	7.83	7.82	7.80
27	7.79	7.77	7.76	7.75	7.73	7.72	7.70	7.69	7.67	7.66
28	7.64	7.63	7.62	7.60	7.59	7.57	7.56	7.54	7.53	7.52
29	7.50	7.49	7.47	7.46	7.44	7.43	7.42	7.40	7.39	7.38
30	7.36	7.35	7.33	7.32	7.31	7.29	7.28	7.26	7.25	7.24

ELEVATION = 500												
<u>TEMP</u>	<u>X.1</u>	<u>X.2</u>	<u>X.3</u>	<u>X.4</u>	<u>X.5</u>	<u>X.6</u>	<u>X.7</u>	<u>X.8</u>	<u>X.9</u>	<u>X.10</u>		
0	14.38	14.34	14.30	14.26	14.22	14.18	14.14	14.10	14.06	14.02		
1	13.98	13.94	13.90	13.87	13.83	13.79	13.75	13.72	13.68	13.64		
2	13.60	13.57	13.53	13.49	13.46	13.42	13.38	13.35	13.31	13.27		
3	13.24	13.20	13.17	13.13	13.10	13.06	13.03	12.99	12.96	12.92		
4	12.89	12.86	12.82	12.79	12.75	12.72	12.69	12.65	12.62	12.59		
5	12.55	12.52	12.49	12.46	12.42	12.39	12.36	12.33	12.29	12.26		
6	12.23	12.20	12.17	12.14	12.11	12.07	12.04	12.01	11.98	11.95		
7	11.92	11.89	11.86	11.83	11.80	11.77	11.74	11.71	11.68	11.65		
8	11.62	11.60	11.57	11.54	11.51	11.48	11.45	11.42	11.40	11.37		
9	11.34	11.31	11.28	11.26	11.23	11.20	11.17	11.15	11.12	11.09		
10	11.07	11.04	11.01	10.99	10.96	10.93	10.91	10.88	10.85	10.83		
11	10.80	10.78	10.75	10.73	10.70	10.68	10.65	10.63	10.60	10.58		
12	10.55	10.53	10.50	10.48	10.45	10.43	10.40	10.38	10.36	10.33		
13	10.31	10.29	10.26	10.24	10.22	10.19	10.17	10.15	10.12	10.10		
14	10.08	10.05	10.03	10.01	9.99	9.96	9.94	9.92	9.90	9.88		
15	9.85	9.83	9.81	9.79	9.77	9.75	9.73	9.70	9.68	9.66		
16	9.64	9.62	9.60	9.58	9.56	9.54	9.52	9.50	9.48	9.45		
17	9.43	9.41	9.39	9.37	9.35	9.33	9.32	9.30	9.28	9.26		
18	9.24	9.22	9.20	9.18	9.16	9.14	9.12	9.10	9.08	9.07		
19	9.05	9.03	9.01	8.99	8.97	8.95	8.94	8.92	8.90	8.88		
20	8.86	8.84	8.83	8.81	8.79	8.77	8.76	8.74	8.72	8.70		
21	8.69	8.67	8.65	8.63	8.62	8.60	8.58	8.57	8.55	8.53		
22	8.52	8.50	8.48	8.46	8.45	8.43	8.42	8.40	8.38	8.37		
23	8.35	8.33	8.32	8.30	8.29	8.27	8.25	8.24	8.22	8.21		
24	8.19	8.17	8.16	8.14	8.13	8.11	8.10	8.08	8.06	8.05		
25	8.03	8.02	8.00	7.99	7.97	7.96	7.94	7.93	7.91	7.90		
26	7.91	7.90	7.88	7.87	7.85	7.84	7.82	7.81	7.79	7.78		
27	7.76	7.75	7.73	7.72	7.70	7.69	7.67	7.66	7.65	7.63		
28	7.62	7.60	7.59	7.57	7.56	7.55	7.53	7.52	7.50	7.49		
29	7.48	7.46	7.45	7.43	7.42	7.41	7.39	7.38	7.36	7.35		
30	7.34	7.32	7.31	7.29	7.28	7.27	7.25	7.24	7.23	7.21		

ELEVATION = 600											
<u>TEMP</u>	<u>X.1</u>	<u>X.2</u>	<u>X.3</u>	<u>X.4</u>	<u>X.5</u>	<u>X.6</u>	<u>X.7</u>	<u>X.8</u>	<u>X.9</u>	<u>X.10</u>	
0	14.32	14.28	14.24	14.20	14.16	14.12	14.08	14.04	14.01	13.97	
1	13.93	13.89	13.85	13.81	13.78	13.74	13.70	13.66	13.63	13.59	
2	13.55	13.51	13.48	13.44	13.40	13.37	13.33	13.30	13.26	13.22	
3	13.19	13.15	13.12	13.08	13.05	13.01	12.98	12.94	12.91	12.88	
4	12.84	12.81	12.77	12.74	12.71	12.67	12.64	12.61	12.57	12.54	
5	12.51	12.47	12.44	12.41	12.38	12.34	12.31	12.28	12.25	12.22	
6	12.19	12.15	12.12	12.09	12.06	12.03	12.00	11.97	11.94	11.91	
7	11.88	11.85	11.82	11.79	11.76	11.73	11.70	11.67	11.64	11.61	
8	11.58	11.55	11.52	11.50	11.47	11.44	11.41	11.38	11.35	11.33	
9	11.30	11.27	11.24	11.21	11.19	11.16	11.13	11.11	11.08	11.05	
10	11.03	11.00	10.97	10.95	10.92	10.89	10.87	10.84	10.82	10.79	
11	10.76	10.74	10.71	10.69	10.66	10.64	10.61	10.59	10.56	10.54	
12	10.51	10.49	10.46	10.44	10.42	10.39	10.37	10.34	10.32	10.30	
13	10.27	10.25	10.22	10.20	10.18	10.16	10.13	10.11	10.09	10.06	
14	10.04	10.02	10.00	9.97	9.95	9.93	9.91	9.88	9.86	9.84	
15	9.82	9.80	9.78	9.75	9.73	9.71	9.69	9.67	9.65	9.63	
16	9.61	9.58	9.56	9.54	9.52	9.50	9.48	9.46	9.44	9.42	
17	9.40	9.38	9.36	9.34	9.32	9.30	9.28	9.26	9.24	9.22	
18	9.20	9.18	9.17	9.15	9.13	9.11	9.09	9.07	9.05	9.03	
19	9.01	9.00	8.98	8.96	8.94	8.92	8.90	8.89	8.87	8.85	
20	8.83	8.81	8.80	8.78	8.76	8.75	8.73	8.71	8.69	8.67	
21	8.66	8.64	8.62	8.60	8.59	8.57	8.55	8.54	8.52	8.50	
22	8.49	8.47	8.45	8.44	8.42	8.40	8.39	8.37	8.35	8.34	
23	8.32	8.30	8.29	8.27	8.26	8.24	8.22	8.21	8.19	8.18	
24	8.16	8.15	8.13	8.11	8.10	8.08	8.07	8.05	8.04	8.02	
25	8.01	7.99	7.98	7.96	7.95	7.93	7.92	7.90	7.89	7.87	
26	7.88	7.87	7.85	7.84	7.82	7.81	7.79	7.78	7.76	7.75	
27	7.74	7.72	7.71	7.69	7.68	7.66	7.65	7.63	7.62	7.61	
28	7.59	7.58	7.56	7.55	7.53	7.52	7.51	7.49	7.48	7.46	
29	7.45	7.44	7.42	7.41	7.39	7.38	7.37	7.35	7.34	7.32	
30	7.31	7.30	7.28	7.27	7.26	7.24	7.23	7.21	7.20	7.19	

ELEVATION = 700												
<u>TEMP</u>	<u>X1</u>	<u>X2</u>	<u>X3</u>	<u>X4</u>	<u>X5</u>	<u>X6</u>	<u>X7</u>	<u>X8</u>	<u>X9</u>	<u>X10</u>		
0	14.27	14.23	14.19	14.15	14.11	14.07	14.03	13.99	13.95	13.91		
1	13.88	13.84	13.80	13.76	13.72	13.69	13.65	13.61	13.57	13.54		
2	13.50	13.46	13.43	13.39	13.35	13.32	13.28	13.25	13.21	13.18		
3	13.14	13.10	13.07	13.03	13.00	12.96	12.93	12.90	12.86	12.83		
4	12.79	12.76	12.73	12.69	12.66	12.62	12.59	12.56	12.53	12.49		
5	12.46	12.43	12.40	12.36	12.33	12.30	12.27	12.23	12.20	12.17		
6	12.14	12.11	12.08	12.05	12.02	11.99	11.95	11.92	11.89	11.86		
7	11.83	11.80	11.77	11.74	11.71	11.68	11.66	11.63	11.60	11.57		
8	11.54	11.51	11.48	11.45	11.42	11.40	11.37	11.34	11.31	11.28		
9	11.26	11.23	11.20	11.17	11.15	11.12	11.09	11.06	11.04	11.01		
10	10.98	10.96	10.93	10.91	10.88	10.85	10.83	10.80	10.78	10.75		
11	10.72	10.70	10.67	10.65	10.62	10.60	10.57	10.55	10.52	10.50		
12	10.47	10.45	10.43	10.40	10.38	10.35	10.33	10.31	10.28	10.26		
13	10.23	10.21	10.19	10.16	10.14	10.12	10.10	10.07	10.05	10.03		
14	10.00	9.98	9.96	9.94	9.92	9.89	9.87	9.85	9.83	9.81		
15	9.78	9.76	9.74	9.72	9.70	9.68	9.66	9.63	9.61	9.59		
16	9.57	9.55	9.53	9.51	9.49	9.47	9.45	9.43	9.41	9.39		
17	9.37	9.35	9.33	9.31	9.29	9.27	9.25	9.23	9.21	9.19		
18	9.17	9.15	9.13	9.11	9.09	9.08	9.06	9.04	9.02	9.00		
19	8.98	8.96	8.95	8.93	8.91	8.89	8.87	8.85	8.84	8.82		
20	8.80	8.78	8.76	8.75	8.73	8.71	8.69	8.68	8.66	8.64		
21	8.62	8.61	8.59	8.57	8.56	8.54	8.52	8.51	8.49	8.47		
22	8.46	8.44	8.42	8.41	8.39	8.37	8.36	8.34	8.32	8.31		
23	8.29	8.28	8.26	8.24	8.23	8.21	8.20	8.18	8.16	8.15		
24	8.13	8.12	8.10	8.09	8.07	8.05	8.04	8.02	8.01	7.99		
25	7.98	7.96	7.95	7.93	7.92	7.90	7.89	7.87	7.86	7.84		
26	7.86	7.84	7.83	7.81	7.80	7.78	7.77	7.75	7.74	7.72		
27	7.71	7.69	7.68	7.67	7.65	7.64	7.62	7.61	7.59	7.58		
28	7.56	7.55	7.54	7.52	7.51	7.49	7.48	7.47	7.45	7.44		
29	7.42	7.41	7.40	7.38	7.37	7.35	7.34	7.33	7.31	7.30		
30	7.29	7.27	7.26	7.24	7.23	7.22	7.20	7.19	7.18	7.16		

ELEVATION = 800											
<u>TEMP</u>	<u>X1</u>	<u>X2</u>	<u>X3</u>	<u>X4</u>	<u>X5</u>	<u>X6</u>	<u>X7</u>	<u>X8</u>	<u>X9</u>	<u>X10</u>	
0	14.21	14.17	14.13	14.09	14.05	14.02	13.98	13.94	13.90	13.86	
1	13.82	13.79	13.75	13.71	13.67	13.63	13.60	13.56	13.52	13.49	
2	13.45	13.41	13.38	13.34	13.30	13.37	13.23	13.20	13.16	13.13	
3	13.09	13.06	13.02	12.99	12.95	12.92	12.88	12.85	12.81	12.78	
4	12.75	12.71	12.68	12.64	12.61	12.58	12.54	12.51	12.48	12.45	
5	12.41	12.38	12.35	12.32	12.28	12.25	12.22	12.19	12.16	12.13	
6	12.10	12.06	12.03	12.00	11.97	11.94	11.91	11.88	11.85	11.82	
7	11.79	11.76	11.73	11.70	11.67	11.64	11.61	11.58	11.55	11.52	
8	11.50	11.47	11.44	11.41	11.38	11.35	11.33	11.30	11.27	11.24	
9	11.21	11.19	11.16	11.13	11.11	11.08	11.05	11.02	11.00	10.97	
10	10.94	10.92	10.89	10.87	10.84	10.81	10.79	10.76	10.74	10.71	
11	10.69	10.66	10.63	10.61	10.58	10.56	10.53	10.51	10.49	10.46	
12	10.44	10.41	10.39	10.36	10.34	10.32	10.29	10.27	10.24	10.22	
13	10.22	10.17	10.15	10.13	10.10	10.08	10.06	10.04	10.01	9.99	
14	9.97	9.95	9.92	9.90	9.88	9.86	9.84	9.81	9.79	9.77	
15	9.75	9.73	9.71	9.68	9.66	9.64	9.62	9.60	9.58	9.56	
16	9.54	9.52	9.50	9.48	9.45	9.43	9.41	9.39	9.37	9.35	
17	9.33	9.31	9.29	9.27	9.25	9.24	9.22	9.20	9.18	9.16	
18	9.14	9.12	9.10	9.08	9.06	9.04	9.02	9.01	8.99	8.97	
19	8.95	8.93	8.91	8.90	8.88	8.86	8.84	8.82	8.80	8.79	
20	8.77	8.75	8.73	8.72	8.70	8.68	8.66	8.65	8.63	8.61	
21	8.59	8.58	8.56	8.54	8.53	8.51	8.49	8.48	8.46	8.44	
22	8.43	8.41	8.39	8.38	8.36	8.34	8.33	8.31	8.29	8.28	
23	8.26	8.25	8.23	8.21	8.20	8.18	8.17	8.15	8.14	8.12	
24	8.10	8.09	8.07	8.06	8.04	8.03	8.01	8.00	7.98	7.97	
25	7.95	7.94	7.92	7.91	7.89	7.88	7.86	7.85	7.83	7.82	
26	7.83	7.81	7.80	7.78	7.77	7.75	7.74	7.73	7.71	7.70	
27	7.68	7.67	7.65	7.64	7.62	7.61	7.60	7.58	7.57	7.55	
28	7.54	7.52	7.51	7.50	7.48	7.47	7.45	7.44	7.43	7.41	
29	7.40	7.38	7.37	7.36	7.34	7.33	7.32	7.30	7.29	7.27	
30	7.26	7.25	7.23	7.22	7.21	7.19	7.18	7.17	7.15	7.14	

ELEVATION = 900											
<u>TEMP</u>	<u>X1</u>	<u>X2</u>	<u>X3</u>	<u>X4</u>	<u>X5</u>	<u>X6</u>	<u>X7</u>	<u>X8</u>	<u>X9</u>	<u>X10</u>	
0	14.16	14.12	14.08	14.04	14.00	13.96	13.92	13.89	13.85	13.81	
1	13.77	13.73	13.70	13.66	13.62	13.58	13.55	13.51	13.47	13.44	
2	13.40	13.36	13.33	13.29	13.25	13.22	13.18	13.15	13.11	13.08	
3	13.04	13.01	12.97	12.94	12.90	12.87	12.83	12.80	12.76	12.73	
4	12.70	12.66	12.63	12.60	12.56	12.53	12.50	12.46	12.43	12.40	
5	12.37	12.33	12.30	12.27	12.24	12.21	12.18	12.14	12.11	12.08	
6	12.05	12.02	11.99	11.96	11.93	11.90	11.87	11.84	11.81	11.78	
7	11.75	11.72	11.69	11.66	11.63	11.60	11.57	11.54	11.51	11.48	
8	11.45	11.43	11.40	11.37	11.34	11.31	11.28	11.26	11.23	11.20	
9	11.17	11.15	11.12	11.09	11.06	11.04	11.01	10.98	10.96	10.93	
10	10.90	10.88	10.85	10.83	10.80	10.77	10.75	10.72	10.70	10.67	
11	10.65	10.62	10.60	10.57	10.55	10.52	10.50	10.47	10.45	10.42	
12	10.40	10.37	10.35	10.33	10.30	10.28	10.25	10.23	10.21	10.18	
13	10.16	10.14	10.11	10.09	10.07	10.05	10.02	10.00	9.98	9.95	
14	9.93	9.91	9.89	9.87	9.84	9.82	9.80	9.78	9.76	9.73	
15	9.71	9.69	9.67	9.65	9.63	9.61	9.59	9.56	9.54	9.52	
16	9.50	9.48	9.46	9.44	9.42	9.40	9.38	9.36	9.34	9.32	
17	9.30	9.28	9.26	9.24	9.22	9.20	9.18	9.16	9.14	9.12	
18	9.11	9.09	9.07	9.05	9.03	9.01	8.99	8.97	8.96	8.94	
19	8.92	8.90	8.88	8.86	8.85	8.83	8.81	8.79	8.77	8.76	
20	8.74	8.72	8.70	8.69	8.67	8.65	8.63	8.62	8.60	8.58	
21	8.56	8.55	8.53	8.51	8.50	8.48	8.46	8.45	8.43	8.41	
22	8.40	8.38	8.36	8.35	8.33	8.31	8.30	8.28	8.27	8.25	
23	8.23	8.22	8.20	8.19	8.17	8.15	8.14	8.12	8.11	8.09	
24	8.08	8.06	8.04	8.03	8.01	8.00	7.98	7.97	7.95	7.94	
25	7.92	7.91	7.89	7.88	7.86	7.85	7.83	7.82	7.80	7.79	
26	7.80	7.79	7.77	7.76	7.74	7.73	7.71	7.70	7.68	7.67	
27	7.66	7.64	7.63	7.61	7.60	7.58	7.57	7.56	7.54	7.53	
28	7.51	7.50	7.48	7.47	7.46	7.44	7.43	7.41	7.40	7.39	
29	7.37	7.36	7.35	7.33	7.32	7.30	7.29	7.28	7.26	7.25	
30	7.24	7.22	7.21	7.19	7.18	7.17	7.15	7.14	7.13	7.11	

					<u>ELEV</u>	ATION = 10	<u>000</u>				
<u>TEN</u>	MP	<u>X1</u>	<u>X2</u>	<u>X3</u>	<u>X4</u>	<u>X5</u>	<u>X6</u>	<u>X7</u>	<u>X8</u>	<u>X9</u>	<u>X10</u>
	0	14.10	14.06	14.03	13.99	13.95	13.91	13.87	13.83	13.79	13.76
	1	13.72	13.68	13.64	13.61	13.57	13.53	13.49	13.46	13.42	13.38
	2	13.35	13.31	13.28	13.24	13.20	13.17	13.13	13.10	13.06	13.03
	3	12.99	12.96	12.92	12.89	12.85	12.82	12.78	12.75	12.72	12.68
	4	12.65	12.62	12.58	12.55	12.52	12.48	12.45	12.42	12.39	12.35
	5	12.32	12.29	12.26	12.22	12.19	12.16	12.13	12.10	12.07	12.04
	6	12.01	11.97	11.94	11.91	11.88	11.85	11.82	11.79	11.76	11.73
	7	11.70	11.67	11.64	11.61	11.58	11.56	11.53	11.50	11.47	11.44
	8	11.41	11.38	11.35	11.33	11.30	11.27	11.24	11.21	11.19	11.16
	9	11.13	11.10	11.08	11.05	11.02	11.00	10.97	10.94	10.92	10.89
	10	10.86	10.84	10.81	10.79	10.76	10.73	10.71	10.68	10.66	10.63
	11	10.61	10.58	10.56	10.53	10.51	10.48	10.46	10.43	10.41	10.38
	12	10.36	10.34	10.31	10.29	10.26	10.24	10.22	10.19	10.17	10.15
	13	10.12	10.10	10.08	10.05	10.03	10.01	9.99	9.96	9.94	9.92
	14	9.90	9.87	9.85	9.83	9.81	9.79	9.76	9.74	9.72	9.70
	15	9.68	9.66	9.64	9.61	9.59	9.57	9.55	9.53	9.51	9.49
	16	9.47	9.45	9.43	9.41	9.39	9.37	9.35	9.33	9.31	9.29
	17	9.27	9.25	9.23	9.21	9.19	9.17	9.15	9.13	9.11	9.09
	18	9.07	9.05	9.04	9.02	9.00	8.98	8.96	8.94	8.92	8.90
	19	8.89	8.87	8.85	8.83	8.81	8.80	8.78	8.76	8.74	8.72
	20	8.71	8.69	8.67	8.65	8.64	8.62	8.60	8.58	8.57	8.55
	21	8.53	8.52	8.50	8.48	8.47	8.45	8.43	8.42	8.40	8.38
	22	8.37	8.35	8.33	8.32	8.30	8.28	8.27	8.25	8.24	8.22
	23	8.20	8.19	8.17	8.16	8.14	8.13	8.11	8.09	8.08	8.06
	24	8.05	8.03	8.02	8.00	7.99	7.97	7.96	7.94	7.93	7.91
	25	7.90	7.88	7.87	7.85	7.84	7.82	7.81	7.79	7.78	7.76
	26	7.77	7.76	7.74	7.73	7.72	7.70	7.69	7.67	7.66	7.64
	27	7.63	7.61	7.60	7.59	7.57	7.56	7.54	7.53	7.51	7.50
	28	7.49	7.47	7.46	7.44	7.43	7.42	7.40	7.39	7.38	7.36
	29	7.35	7.33	7.32	7.31	7.29	7.28	7.27	7.25	7.24	7.22
	30	7.21	7.20	7.18	7.17	7.16	7.14	7.13	7.12	7.10	7.09

D-2. ¹Solubility of oxygen in pure water at different temperatures.

TEMP	mg/L	TEMP	mg/L	TEMP	mg/L
0	14.16	12	10.43	24	8.25
1	13.77	13	10.2	25	8.11
2	13.4	14	9.98	26	7.99
3	13.05	15	9.76	27	7.86
4	12.7	16	9.56	28	7.57
5	12.37	17	9.37	29	7.64
6	12.06	18	9.18	30	7.53
7	11.76	19	9.01	31	7.42
8	11.47	20	8.84	32	7.32
9	11.19	21	8.68	33	7.22
10	10.92	22	8.53	34	7.13
11	10.67	23	8.38	35	7.04

D-3. ²Correction factor for oxygen saturation at varying altitudes.

Altitude Correction

Altitude Correction							
(feet)	(meters)	Factor					
0	0	1					
500	152	0.98					
1000	305	0.96					
1500	457	0.95					
2000	610	0.93					
2500	762	0.91					
3000	914	0.89					
3500	1067	0.88					
4000	1219	0.86					

1372

To determine calibration value:

4500

- 1. Obtain oxygen value form solubility table;
- 2. Obtain factor from correction table for altitude you are at;
- 3. Multiply oxygen value by correction factor, calibrate using this value.

0.84

¹Water quality in warmwater fish ponds, C.E. Boyd, 1979

²British Columbia, Ministry of Environment, Lands, and Parks web site: http://wlapwww.gov.bc.ca/wat/wq/BCguidelines/do/do-01.htm

Appendix E Kentucky Ambient/Watershed Monitoring Assessment Program Contamination Control

Kentucky Ambient/Watershed Monitoring Assessment Program Contamination Control

I. Contamination Problems

- A. Preventing ambient water samples from becoming contaminated during the sampling and analytical process is one of the greatest challenges faced in the generation of water quality information. It is imperative that extreme care be taken to avoid contamination when collecting and analyzing ambient water samples.
- B. There are numerous routes by which samples may become contaminated. Potential sources of contamination during sampling include: metallic or metal-containing sampling equipment, containers, labware (e.g. talc gloves that contain high levels of zinc), reagents and deionized water; improperly cleaned and stored equipment, labware, reagents; atmospheric inputs such as dirt and dust from vehicular exhaust; cigarette smoke, nearby roads, bridges, wires and poles; and human contact.

II. Contamination Control

- A. Philosophy- The philosophy behind contamination control is to ensure that any object or substance that contacts the sample is free from any material that may bias results of variables of concern.
 - 1. The integrity of the results produced cannot be compromised by contamination of samples. Requirements and suggestions for controlling sample contamination are given in this manual.
 - 2. While contamination control is essential, personnel health and safety remain the highest priority. Requirements and suggestions for personnel safety are given in STEP 7 of this manual.
- B. Avoiding contamination- The best way to control contamination is to completely avoid exposure of the sample to contaminants in the first place. Avoiding exposure means performing operations in an area known to be free from contamination. Two of the most important factors in avoiding/reducing sample contamination are (1) an awareness of potential sources of contamination and (2) strict attention to work being performed. Therefore, it is imperative that the procedures described in this manual be carried out by well-trained, experienced personnel. Documentation of training should be kept on file and be readily available for review.
- C. Minimize exposure- The weighted bottle sampler (WBS) should be sprayed periodically with an epoxy-based paint (provided by Ambient/Watershed

Coordinator). Frequency of spraying depends on the rate at which paint is chipped off as happens during the course of sampling. Spraying is to be performed to eliminate/reduce chance of metal sampler contaminating metals samples.

- D. Wear gloves- Sampling personnel must wear clean, powder-free gloves during all operations involving the WBS, samples and blanks. If another object is touched before handling samples, the glove(s) must be changed before handling the samples. Wearing multiple layers of clean gloves will allow the old pair to be quickly stripped with minimal disruption to the work activity. Glove boxes are to be stored in ziplock bags to reduce possibility of contamination. Gloves are to be taken from box only immediately prior to handling of samples. An alternative is to place clean gloves in a ziplock bag, removing gloves prior to sample handling.
- E. Use variable-free materials- All equipment used for collecting samples (e.g. sample bottles) must be free of contaminates which could bias analytical results.
- F. Construction materials- Only those bottles provided by the Ambient Monitoring Coordinator are to be used in collecting and storing water samples. Bottles designated for metals, mercury and pesticides have been precleaned by the vendor. When vendors are changed, deionized water blanks will be analyzed to ascertain cleanliness.
- G. When using the DH-81 sampler- the US D-95 cap and US D-77 nozzle are to be cleaned following STEP 6. When using the DH-81 sampler, an equipment blank must be analyzed for each group of cleaned samplers.
- H. Avoid sources of contamination- Avoid contamination by being aware of potential sources and routes of contamination.
- I. Contamination by carryover- Contamination may occur when a sample containing low concentrations of variables of interest is processed immediately after a sample containing relatively high concentrations of these variables. To eliminate/reduce the issue of carryover, samples are collected directly into sample bottles. When using the DH-81 sampler, samplers and funnels are to be used at one site only.
- J. Contamination by airborne particulate matter- Less obvious substances capable of contaminating samples include airborne particles. Samples may be contaminated by airborne dust, dirt, particulate matter or vapors from vehicular exhaust; cigarette smoke; nearby corroded or rusted bridges, pipes, poles or wires; nearby roads; and even human health. When possible, the sampling activity should occur as far as possible from sources of airborne contamination.

Appendix F Quality Control Design

Quality Control Design

The primary goal of the Kentucky Ambient/Watershed Monitoring Assessment (KENTUCKY AMBIENT/WATERSHED MONITORING ASSESSMENT) program is to provide legally defensible water quality information. This information is used to assess use support and water quality variable trends in Kentucky's lakes and rivers. To interpret water quality data properly, information is needed to estimate the bias and variability that result from sample collection, sample processing and chemical analysis. Bias is the systematic error inherent in a method and may be either positive or negative. Variability is the degree of random error in repeated measurements of the same quantity.

The objectives in evaluating sampling bias and variability for surface water chemical analyses are to determine the extent to which:

- 1. Sampling methods and equipment introduce contaminants (positive bias) into water samples.
- 2. Sample matrix interference or analyte degradation affect the recovery (bias and variability) of organic samples.
- 3. Sample collection, processing and analysis affect the variability of measured constituent concentrations.

Quality assurance of field measurements is determined through twice yearly meter audits. Quality assurance of surface water chemical data is determined from routine quality control (QC) samples used to meet these objectives and to evaluate potential effects on the interpretation of environmental data. Quality control objectives are listed in Table F-1.

Table F-1. Quality control objectives (RPD, relative percent difference)

Variable	Accuracy	Precision	Completeness	
Field Measurements:				
Water temperature	±0.5 degrees C	RPD within 20%	90%	
Specific conductance	±5% of meter range	RPD within 20%	90%	
PH	±0.2 SU	RPD within 20%	90%	
Dissolved Oxygen	±5%	RPD within 20%	90%	
	-L	<u> </u>		
Surface water chemic	al analysis:			
Total organic carbon	±3% of known conc.	RPD within 20%	90%	
Suspended sediment	±3 standard deviations	RPD within 20%	90%	
-	of known conc.			
Major ions	Same as above	RPD within 20%	90%	
Nutrients	Same as above	RPD within 20%	90%	
Trace elements	Same as above	RPD within 20%	90%	
Pesticides		RPD within 20%	90%	

Field Measurements

Field meter audits involve the shipping of audit unknowns for specific conductance and pH to all personnel involved in monitoring. Reports of measured unknowns are sent from the field offices to the Ambient Monitoring Coordinator. Once all reports are received, a most probable number is determined based on all received reports. Reported measurements are then evaluated for precision. All field probes in use (Hydrolab) are reported by the manufacturer to have an accuracy of ± 0.2 pH units.

Surface Water Chemical Data

Two types of QC samples are to be collected. Blanks are used to estimate bias. Replicates are used to estimate variability.

Field blanks

A blank is a water sample that is intended to be free of analytes of interest. Blank samples are analyzed to test for bias that could result from contamination of environmental samples by the analytes of interest during any stage of sample collection, processing and analysis. A field blank is prepared in the field and used to demonstrate that: (1) sample collection and processing have not resulted in contamination and (2) sample handling and transport have not introduced contamination. In addition, because the field blank is treated like an environmental sample at the laboratory, it includes potential contamination introduced during laboratory handling and analysis.

Field blanks should be prepared immediately before collecting and processing an environmental sample at a selected site. Use only deionized water from the Division of Environmental Services. Water designated for field blanks will be provided by Ambient Monitoring Coordinator.

- 1. For mercury field blanks pour ultra pure DIW into the sample bottle. Cap and shake.
- 2. For dissolved metals field blanks filter 500 ml of ultra pure DIW as outlined in Appendix I.
- 3. Preserve the samples according to STEP 11.

Replicate samples

Replicates are two or more samples collected so that the samples are considered identical in composition. Replicate samples as used in the KENTUCKY AMBIENT/WATERSHED MONITORING ASSESSMENT are concurrent samples. Concurrent replicates are multiple (usually 2) samples collected from an environmental matrix as close as possible to the same location and time. These replicates account for variability introduced by sample collection, processing and analysis.

1. Rinse sample bottles with native stream water.

- 2. For each variable group specified by the sample plan, collect a pair of replicate concurrent samples.
- 3. Preserve as outlined in STEP 11.

Frequency, timing and collection of QC samples

The minimum number of each type of QC sample required to meet the stated QC objectives is listed in Table F-2.

In order not to overload the DES laboratory, initial collection of field blank and duplicate samples will be gradually introduced. A list of when to make the initial collection will be sent to the regional offices by the Ambient Monitoring Coordinator. Subsequent QC samples should be collected on a yearly basis, determined from the initial sample date. Field blanks can be prepared at any surface water site; however, certain sites should be targeted to test greatest potential risk of contamination. Duplicates should be targeted at sites and times where concentrations of at least some target analytes are expected to exceed detection limits. Surface water samples collected by more than one sampling-team should prepare and submit a field blank and duplicate. The goal is to evaluate each sampling team and set of equipment often enough to ensure that procedures are adequate or that corrective actions are taken.

Table F-2. ¹Collection frequencies for routine quality control samples.

Constituent or group	Number of QC samples/total number of environmental samples						
	Field blanks Duplicates						
Major ions	1 per 20	1 per 20					
Nutrients	1 per 20	1 per 20					
Pesticides	1 per 20	1 per 10					
Metals (total recoverable)	1 per 20	1 per 15					
Metals (dissolved)	1 per trip	5% of samples over sample period.					

¹If number of QC samples for a given sampling year (April through March) is less than number in Table F-2, collect samples on an annual basis.

Appendix G Chain of Custody

AMBIENT/ WATERSHED MONITORING CHAIN OF CUSTODY DIVISION OF WATER

	Samp	ler ID:	law Kild	· ·							
REPORT	NUMBER	L: A19 - 10967 L	ABORATORY NUMBI	ER: 02-4/019							
Site Ident		= -	ollection Date/Time	,							
Location: _	Pond R.	re-Sermento Date	2000/12/10 Time: /	020 hrs							
Station #: _	PRIOIZ	Date:	unty Name: McLeav	· · · · ·							
Field Mea	surements	•									
Temp:	19Sp. C	Cond.: <u>7/4</u> pH:	8 D.O.: //, b Tu	rbidity: <u>30,9</u>							
		tipedown USGS w									
	Matrix Requested Container Size, Type Preservation Method Variables Water /Sediment OH										
	6.0	1 liter, HDPE bottle	Cool to 4 degrees C	Bulk variables							
	. S.O	1 liter, HDPE bottle	Cool to 4 degrees C, H2SO4 < pH 2.0	Nutrients							
1	ನಿ.೦	1 liter. HDPE bottle	Cool to 4 degrees C, HNO3 < pH 2.0	Metals							
) .O	I liter, amber glass bottle	5 ml HCL, cool to 4 degrees C	Low level Hg							
	·	1 liter, amber glass bottle	Cool to 4 degrees C	N/P Pesticides Method 507/ 508							
		1 liter, amber glass bottle	Cool to 4 degrees C	Herbicides Method 515.1							
		120 ml, amber glass bottle	Cool to 4 degrees C, 4 ml monochloracetic acid	Carbamates Method 531.1							
-		120 ml, amber glass bottle	Cool to 4 degrees C	Glyphosate (Roundup)							
		120 ml, coliform sample bottle/ Whirlpak	Cool to 4 degrees C	Fecal Coliform							
		y polyethylene plastic Sulfuric <i>SAOIS 7090</i> Nitr	ic NAO/57080 Hydrochl	oric <u>HA 2043/10</u>							
Signatur Relinquishe		- stal	Date! 4/3/02_ Tim	e: 1400							
Received b	y: Qun	nes Clark	Date: 12-11-02 Tim	e: <u>)(00</u>							
Relinquish	ed by:		Date:Tim	e:							
Received b	у:		Date: Tim	ie:							

FIELD OBSERVATIONS

Sampling location: Bridge; In-stream (wading); Boat; Lat/long:
Flow conditions:
Dry Low Normal Above Normal Flood
Hydrologic condition (if possible to determine):
Stable Falling Peak
Weather (at time of sampling):
Cloud cover: Sunny Partly Cloudy Overcast
Air temperature: Freezing (<32 degrees) Cold (above 32 degrees to 50 degrees) Mild (above 50 degrees to 80 degrees) Hot (above 80 degrees to 95 degrees) Very hot (>95 degrees) Precipitation: Fog Drizzle Rain Snow/sleet
Weather in past 24 hours:
Storm (heavy rain) Rain (steady rain) Showers (intermittent rain) Overcast Clear/Sunny
Stream mixing: Excellent Good Fair Poor
If mixing fair or poor, why
Stream color: brown green blue clear other (explain)
Observations: Floating woody debris Floating garbage Algal mats Fish kill Detergent suds Odor Oil/Grease
Stream shading (evaluate in summer months): fully canopied partially canopied not shaded
General observations:

Apppendix H Lake Data Sheet

STATI	ON NUMB	ER:	LAKE STATION NAME:						
DATE yr	mo da		TIME: SITE COLLECTED:						
Fic	eld Data	2	Unit	Code	Value				
	chi Dis sparenc		Meters	00078		Secchi Disk: (Ft.)			
Depth	(Maxim	um)	Meters	00205					
Euphoti	c Zone	Depth	Meters	00204			Foot Candles:		
Depth 00098	Temp 00010	рН 00400	DO 00299	Cond 00094	Depth 00098	Temp 00010	Temp pH DO Co		
Surface					16m				
1m					17m				
2m					18m			·	
3m					19m		·		
4m					20m		:		
5 m			·		21m				
6m					22m				
7m					23m				
8m					24m				
9m					25m				
10m					3 0 m				
11m	·				35m				
12m					40m				
13m		1			45m				
14m					50m				
15m					55m	ŕ			`

STATION	NUMBER	CLN_	DATE_		/ /	TIME	:
	•		yr	mon	day	24	hr.

Euphotic Zone:

Depth in Meters

Laboratory Data	Unit	Code	Remark		
NH ₃ -N	mg/l	00610	х		
No2+NO3-N	mg/l	00630	х		
TKN	mg/l	00625	x		
Phosphorus, total	mg/l	00665	x		
Phosphorus, dissolved	mg/l	00666	х		1
Phosphorus, ortho	mg/l	00671	х		
Chlorophyll a (plankton)	mg/l	32209	X		
Alkalinity	mg/l	00410	Х		
Chlorides	mg/l	00940	х		· .
Sulfates	mg/l	00946	x		

Appendix I Dissolved Metals – Clean Field Sampling Protocol

Dissolved Metals – Clean Field Sampling Protocol

The purpose of this section is to present the standard operating procedures for collection and processing of water samples for determination of dissolved metals. Dissolved metals are those metals that pass through a $0.45~\mu m$ pore size capsule filter. Capsule filters are disposable, self-contained units composed of a pleated filter medium encased in a plastic housing that can be connected in-line to a sample-delivery system (peristaltic pump) that generates sufficient pressure to force water through the filter.

The specific procedures include:

- 1. Office Preparations and Cleaning of Equipment;
- 2. Field Rinsing of Equipment Prior to Sampling;
- 3. Sample Processing and Preservation; and
- 4. Quality Assurance

I. Office Procedures and Cleaning of Equipment

Requisite Supplies

- 1. Ultra pure deionized water (UPDIW); UPDIW may be stored in a pre-cleaned HDPE (high density polyethelene) container.
- 2. Concentrated, trace-metal free (HCl) acid. Aliquots must be diluted with UPDIW to 5% and stored in a non-contaminating container.
- 3. Assorted safety-labeled wash bottles for UPDIW and dilute acid.
- 4. Liquid detergent (Liquinox) that does not contain either phosphates or NTA.
- 5. Disposable, non-powdered vinyl gloves.
- 6. Non-contaminating, non-metallic, clear/uncolored polypropylene/high density polyethylene basins.
- 7. Ziplock bags

Cleaning Procedure

Follow procedure in STEP 6 with following modifications:

- 1. Place ends of silicone tubing in wash basins. Run mid-section of tubing through peristaltic pump. Soak for thirty minutes by turning on pump and circulating wash solutions through tubing.
- 2. Double bag cleaned tubing and bottles.
- 3. After bottles are cleaned, fill with small amount of DIW to be discarded at time of sampling.

II. Field Rinsing of Equipment Prior to Sampling

Field rinsing is required to ensure that all cleaning solution residues are removed and to equilibrate the sampling equipment to the sampling environment.

Requisite Supplies

1. Disposable, non-powdered vinyl gloves.

Procedure

- 1. Put on pair of disposable gloves.
- 2. Collect sufficient quantities of stream water following procedures listed for wading or bridge sampling in STEP 9.

III. Sample Processing and Preservation

As noted in the opening, the definition of a dissolved constituent is an operational definition based on filtration through a 0.45 μ m membrane filter. Trace metals will be processed through a 0.45 μ m capsule filter. Processing and preservation protocols utilize the "Clean"/"Dirty" hands protocol. Ideally two individuals should perform this protocol.; however, the protocol can be performed by a single individual. Powder-free gloves are required in both the processing and preservation steps. If a single person is performing the sample collection from a bridge, multiple glove changes will be required. Gloves must be changed each time they are contaminated. Gloves are considered contaminated whenever they come in contact with any material other than the sample bottles and caps.

Requisite Supplies

- 1. Deionized water
- 2. Disposable non-powdered vinyl gloves.
- 3. Capsule filters.
- 4. Peristaltic pump and pump tubing (the peristaltic pump used by the Division of Water is powered off the vehicle battery) (silicon tubing size is 0.1924 in. [inner diameter] X 0.3915 in. [outer width] and 3 ft. in length).
- 5. Pre-cleaned sample bottle and weighted bottle sampler (if sampling non-wadeable stream).
- 6. Processing/preservation chamber (design described in STEP 11).
- 7. New capsule filters and silicon tubing are required for each new sampling site.

Procedure

1. Collect the whole-water sample, using the appropriate sampling procedure as presented in STEP 9 for site and flow conditions. It is important to remain cognizant of potential sources of contamination when sampling, limiting

sources of contamination. When sampling from metallic structures, it may be useful to spread a large plastic sheet over the area where sampling is to take place. If the sampler makes contact with a potential contaminant, dispose of gloves and put on a new pair. Try to time sampling to periods of low traffic flow. When sampling is completed, return to vehicle for sample processing. If bridge sampling, disassemble traffic work zone set up and drive to nearby offroad parking site.

- 2. Park the field vehicle away from highway and turn motor off. Road dust and emissions from vehicles can contaminate trace metal samples for microgramper-liter analysis. The open door from the vehicle should face away from the highway. Put on disposable gloves.
- 3. Set up processing/preservation chamber; set up peristaltic pump with tubing; make two small holes in side of chamber and run ends of tubing into chamber. Change gloves. Attach capsule filter to one end of the tubing.
- 4. Inside of chamber place HDPE container containing UPDIW; also place a container for "waste" UPDIW, bottle containing sample and 500 mL bottle to receive filtered sample.
- 5. Pass 500 mL of UPDIW through the pump tubing and through capsule filter. After passage of the UPDIW, remove the tubing from the UPDIW reservoir and continue to run the pump to drain as much of the fluid remaining in the system as possible. Shaking the capsule filter may facilitate removal of the entrained water. Discard all the fluid.
- 6. Transfer the pump tubing to the bottle containing sample.
- 7. Start up peristaltic pump and filter about 50 mL of sample water into waste container.
- 8. Transfer capsule filter over the sample bottle opening and filter about 25 mL into bottle. Cap and shake bottle to rinse. Pour into waste container.
- 9. Process the filtered trace metal sample by filling the rinsed bottle.
- 10. Once filtration is completed, add 0.5 mL of HNO₃ to bottle.
- 11. Place filtered sample into sealable bag and place on ice in cooler.
- 12. Disassemble processing/preservation chamber.

Quality Control Procedures for Dissolved Metals

Field collected quality control samples are required for evaluating the quality of the sampling and processing procedures as well as for the actual data. Without quality control data, the sample data cannot be adequately interpreted because errors associated with the sample data are unknown. Quality control in the overall monitoring program is presented in Appendix F.